

# **Siemens TCP/IP Ethernet Driver Help**

**© 2015 Kepware Technologies**

# Table of Contents

<b>Table of Contents</b> .....	<b>2</b>
Siemens TCP/IP Ethernet Driver Help .....	5
Overview .....	5
<b>Device Setup</b> .....	<b>6</b>
Communications Parameters .....	7
S7 Communications Parameters .....	7
Addressing Options .....	9
Tag Import .....	10
Cable Diagrams .....	12
How To Configure S7-200 Connections in Micro/WIN .....	13
How To Configure S7-300/400 Connections in STEP 7 .....	27
How To Configure S7-1200 Connections with the Totally Integrated Automation (TIA) Portal .....	31
How To Configure S7-1500 Connections .....	35
<b>Optimizing Siemens TCP/IP Ethernet Communications</b> .....	<b>37</b>
<b>Data Types Description</b> .....	<b>38</b>
<b>Address Descriptions</b> .....	<b>39</b>
S7-200 Address Descriptions .....	39
S7-300 Address Descriptions .....	41
S7-400 Address Descriptions .....	41
S7-1200 Address Descriptions .....	41
S7-1500 Address Descriptions .....	42
NetLink: S7-300 Address Descriptions .....	42
NetLink: S7-400 Address Descriptions .....	42
Internal Tags .....	43
Standard S7-300/400/1200/1500 Item Syntax .....	43
Applicom Direct-Link Item Syntax .....	48
INAT OPC Server TCPIPH1 Item Syntax .....	50
Siemens Simatic Net Item Syntax .....	52
Siemens STEP 7 Item Syntax .....	54
Softing S7/S5 OPC Server Item Syntax .....	56
Legacy S7-300/400 Item Syntax .....	58
<b>Error Descriptions</b> .....	<b>63</b>
Error Codes .....	63
Address Validation Error Messages .....	64
Address <address> is out of range for the specified device or register. ....	64
Array size is out of range for address <address>. ....	64
Array Support is not available for the specified address: <address>. ....	64

Data type <type> is not valid for device address <address> . . . . .	65
Device address <address> contains a syntax error. . . . .	65
Device address <address> is read only. . . . .	65
Missing address. . . . .	65
Automatic Tag Generation Error Messages . . . . .	65
Language file warning for device <channel.device> : Memory exception reading the STEP 7 language file. . . . .	66
Language file warning for device <channel.device> : STEP 7 language file failed to open [Reason]. . . . .	66
Language file warning for device <channel.device> : Unable to load STEP 7 language file. . . . .	66
String conversion warning: Auto generated tag names and descriptions may not appear as expected for device <channel.device>. . . . .	67
Unable to generate a tag database for device <channel.device>. Reason: The STEP 7 project file has not been specified. . . . .	67
Unable to generate a tag database for device <channel.device>. Reason: The program path has not been specified. . . . .	67
Unable to generate a tag database for device <device name>. Reason: <model> devices do not support auto tag database generation. . . . .	67
Unable to generate a tag database for device <device name>. Reason: Failed to read data from the STEP 7 project. . . . .	68
Unable to generate a tag database for device <device name>. Reason: File system error processing the STEP 7 project. . . . .	68
Unable to generate a tag database for device <device name>. Reason: Internal driver error occurred. . . . .	68
Unable to generate a tag database for device <device name>. Reason: The specified CPU is not supported. . . . .	69
Unable to generate a tag database for device <device name>. Reason: Unable to open STEP 7 project. . . . .	69
Unable to generate tag(s) on device <device> for <data block name> data block <data block number>. . . . .	69
Unable to generate tag(s) on device <device> for <tag group>. Array tag not supported for data type <data type>. Tag <tag name> not created. . . . .	69
Unable to generate tag(s) on device <device> for <tag group>. Created tag <tag name> with address <tag address> due to internal block size. . . . .	70
Windows code page warning for device <channel.device> : A required code page (<nxxx>) is unavailable on this machine. Tag generation may fail or tag names and descriptions may not appear as expected. . . . .	70
Driver Error Messages . . . . .	70
Winsock initialization failed (OS error=n). . . . .	71
Winsock V1.1 or higher must be installed to use the Siemens TCP/IP Ethernet device driver. . . . .	71
Device Status Error Messages . . . . .	71
Device <device name> is not responding. . . . .	72
Unable to connect to device <device name>. Device returned transport error [Code=<code>]. . . . .	72
Unable to connect to device <device name>. Frame contains errors. . . . .	73
Unable to establish association with device <device name>. Device returned protocol error [Class=<class>, Code=<code>]. . . . .	73
Unable to establish association with device <device name>. Device returned transport error [Code=<code>]. . . . .	74
Unable to establish association with device <device name>. Frame contains errors. . . . .	74

Unable to read <block size> bytes starting at address <address> on device <device name>. Device returned data access error [Code=<code>].	75
Unable to read <block size> bytes starting at address <address> on device <device name>. Device returned protocol error [Class=<class>, Code=<code>].	76
Unable to read <block size> bytes starting at address <address> on device <device name>. Device returned transport error [Code=<code>].	76
Unable to read <block size> bytes starting at address <address> on device <device name>. Frame contains errors.	77
Unable to read <block size> bytes starting at address <address> on device <device name>. NetLink returned error [Code=<code>].	77
Unable to write to <address> on device <device name>. Device not responding.	78
Unable to write to <address> on device <device name>. Device returned data access error [Code=<code>].	78
Unable to write to <address> on device <device name>. Device returned protocol error [Class=<class>, Code=<code>].	79
Unable to write to <address> on device <device name>. Device returned transport error [Code=<code>].	79
Unable to write to <address> on device <device name>. Frame contains errors.	79
Unable to write to <address> on device <device name>. NetLink returned error [Code=<code>].	79
Unable to write to <address> on device <device name>. Time of Day string <write string> contains a syntax error. Expected hh:mm:ss.hhh format.	80
Unable to write to address <address> on device <device>. Date string <write string> contains a syntax error. Expected yyyy-mm-dd format.	80
Unable to write to address <address> on device <device>. Time string <write string> contains a syntax error. Expected ddD_hhH_mmM_ssS_hhhMS format.	80
<b>Index</b>	<b>81</b>

---

**Siemens TCP/IP Ethernet Driver Help**

---

Help version 1.065

**CONTENTS****Overview**

What is the Siemens TCP/IP Ethernet Driver?

**Device Setup**

How do I configure a device for use with this driver?

**Optimizing Siemens TCP/IP Ethernet Communications**

How do I get the best performance from the Siemens TCP/IP Ethernet Driver?

**Data Types Description**

What data types does this driver support?

**Address Descriptions**

How do I address a data location on a Siemens TCP/IP device?

**Error Descriptions**

What error messages does the Siemens TCP/IP Ethernet Driver produce?

---

**Overview**

---

The Siemens TCP/IP Ethernet Driver provides a reliable way to connect Siemens TCP/IP Ethernet devices to OPC client applications, including HMI, SCADA, Historian, MES, ERP, and countless custom applications. It is intended for use with Siemens S7-200, 300, 400, and 1200 PLCs. There are two options for communications:

- Industrial Ethernet TCP/IP interface communication processor (CP). The protocol used is S7 Messaging on Industrial Ethernet (ISO 8073 Class 0) over TCP/IP as defined in RFC1006.
- Hilscher's NetLink adapter. Only an MPI port is required. The Netlink adapter does not support the S7-200 model.

The driver requires no special libraries or hardware. A standard Ethernet card is all that is needed.

## Device Setup

---

### Supported Devices

S7-200 via CP243  
S7-300 via CP343  
S7-400 via CP443  
S7-1200\*  
S7-1500\*  
S7-300 via NetLink  
S7-400 via NetLink

\*This device has a built-in Ethernet module.

### Supported NetLink Cables and Gateways

NT 50-MPI  
NL 50-MPI  
NL-MPI

### Connection Timeout

This parameter specifies the time that the driver will wait for a connection to be made with a device. Depending on network load, the connect time may vary with each connection attempt. The valid range is 1 to 30 seconds. The default setting is 3 seconds.

### Request Timeout

This parameter specifies the time that the driver will wait on a response from the device before giving up and going on to the next request. Longer timeouts only affect performance if a device is not responding. The valid range is 100 to 30000 milliseconds. The default setting is 2000 milliseconds.

### Retry Attempts

This parameter specifies the number of times that the driver will retry a message before giving up and going on to the next message. The valid range is 1 to 10. The default setting is 2.


### Device IDs

Up to 1024 devices may be defined on a given channel. The device ID is formatted as *YYY.YYY.YYY.YYY*, where *YYY* designates the device's IP address. Each *YYY* byte should be in the range of 0 to 255. If the device supports host name resolution, the device ID may also be specified as a standard UNC/DNS name.

### Note:

For NetLink users, NetLink communication parameters (such as IP Address, Subnet Mask, and Baud Rate) can be configured using the NetLink Configuration utility. This application is located in the server's Utilities sub-directory and can be launched using the Start menu shortcut.

## Communications Parameters



Descriptions of the parameters are as follows:

- **Port Number:** This parameter specifies the port number that the remote CP is configured to use. The default setting for IE TCP/IP is 102 (TSAP). The default setting for NetLink is 1099.

**Note:**

It is recommended that the default port be used for most applications, where the OPC server and the PLC exist on the same network. For an application that will be using the Internet through firewalls and advanced routers, the port number can be changed to allow these operations to occur. In most cases, however, the PLC will only accept a connection on port 102/1099 and may require router forwarding.

- **MPI ID:** This parameter is for NetLink only, and is configured for the port in which the NetLink adapter is connected. It does not apply to models utilizing the IE TCP/IP CPs (such as S7-300 and S7-400). A maximum of two connections or devices via TCP are possible when using the NetLink adapter.

## S7 Communications Parameters

### S7-200 Communications Parameters

There are two ways the Siemens TCP/IP Ethernet Driver can communicate to the S7-200 device on an Ethernet network.

- PG connection (such as, a connection utilized by Micro/WIN). One connection is available.
- Configured connection (such as, a connection configured in Micro/WIN via the Ethernet Wizard). Eight connections are available.

**Note:**

Configured connections are recommended because they free the PG port for Micro/WIN and also provide flexibility to make multiple concurrent connections.

### Local TSAP

Link Type	TSAP Value (hex)
PG	4B57 ('KW')
Configured	A remote (client) TSAP configured in Micro/WIN's Ethernet wizard. If Micro/WIN remote TSAP=xx.yy*, set local TSAP to xxyy.

### Remote TSAP

Link Type	TSAP Value (hex)
PG	4B57 ('KW')
Configured	A local (server) TSAP configured in Micro/WIN's Ethernet wizard. If Micro/WIN remote TSAP=xx.yy*, set local TSAP to xxyy.

\*TSAP as displayed in Micro/WIN's Ethernet Wizard. When accessed from V memory, the value may be in decimal form. For example, if TSAP is 10.00, the V memory value will be 1000 hex or 4096 decimal. The values entered for Local TSAP must be in hexadecimal notation; in this example, the value 1000 would be entered.

### General Rule From the Perspective of the OPC Server

Local TSAP=Micro/WIN remote TSAP  
Remote TSAP=Micro/WIN local TSAP

For information on using the CP243-1 module, refer to [How to Configure S7-200 Connections in Micro/WIN](#).

### S7-300/400/1200/1500 Communications Parameters

This setting does not apply to models utilizing the NetLink adapter (NetLink: S7-300 and NetLink: S7-400).

### Link Settings

The communication link refers to the connection between the Siemens TCP/IP Ethernet Driver and the CP.

#### Type

The type of link chosen determines the number of simultaneous requests allowed. The greater the number of simultaneous requests, the greater the data throughput. Each device connection is allowed one outstanding request. To achieve multiple simultaneous requests, multiple connections must be configured. This is achieved by defining the device multiple times in the OPC server (identical device properties). The devices can be defined within the same channel or under separate channels. For more information, refer to [Optimizing Siemens TCP/IP Ethernet Communication](#).

Channel.Device=1 CP connection

There are three types of links: PC (applications), OP (operator panel), and PG (programming device). OP and PG are usually reserved but can be used if all PC connections are taken.

Type	S7-300 CPU 314, 315	S7-400 CPU 412, 413	S7-400 CPU 414	S7-400 CPU 416
PC	2	14	30	62
OP	1	1	1	1
PG	1	1	1	1

### Default Number Simultaneous Requests

#### Example:

Given an S7-400 CPU 412, 14 simultaneous requests can be achieved by defining 14 identical devices in the OPC server with all configured for Link Type PC. In addition to the PC connections, two more devices can be configured for Link Type OP and PG. This provides 16 connections overall.

**Caution:** Connection resources are shared amongst applications communicating with the CP. If another application such as STEP 7 is configured to use Industrial Ethernet over TCP/IP, at least one PG/PC connection must be left open for that application to use.

#### Note:

For information on increasing the number of PG, OP and PC type connections, refer to [How to Configure S7-300/400 Connections in STEP 7](#).

### CPU Settings

The following settings must match the values entered in STEP 7's HW configuration program.

#### Rack




This parameter specifies the number of the rack in which the CPU of interest resides. For information on how to read/write the rack number using an internal tag, refer to [Internal Tags](#).

**CPU Slot**

This parameter specifies the number of the slot in which the CPU of interest resides. For information on how to read/write the slot number using an internal tag, refer to [Internal Tags](#).

**Addressing Options**

This dialog is used to set the byte order for 16-bit and 32-bit values. Options include **Big Endian (S7 Default)** or **Little Endian**.



**Note:**

Big Endian uses bytes ordered from highest to lowest. Little Endian uses bytes ordered from lowest to highest. The bit order is never changed with either of these methods.

**Big Endian**

DWord 1																															
-	-	-	-	-	-	-	-	1-	1-	1-	1-	1-	-	-	2-	2-	2-	2-	1-	1-	1-	1-	3-	3-	2-	2-	2-	2-	2-	2-	
7	6	5	4	3	2	1	0	5	4	3	2	1	0	9	8	3	2	1	0	9	8	7	6	1	0	9	8	7	6	5	4
Word 1														Word 3																	
-	-	-	-	-	-	-	-	1-	1-	1-	1-	1-	-	-	7	6	5	4	3	2	1	0	1-	1-	1-	1-	1-	1-	9	8	
7	6	5	4	3	2	1	0	5	4	3	2	1	0	9	8	7	6	5	4	3	2	1	0	5	4	3	2	1	0	9	8
Byte 1								Byte 2								Byte 3								Byte 4							
-	-	-	-	-	-	-	-	7	6	5	4	3	2	-	-	7	6	5	4	3	2	1	0	7	6	5	4	3	2	1	0
7	6	5	4	3	2	1	0	7	6	5	4	3	2	1	0	7	6	5	4	3	2	1	0	7	6	5	4	3	2	1	0

**Bits**

1. The bit range for DWord 1 is 31-0.
2. The bit range for Word 1 and Word 3 is 15-0.

- The bit range for Byte 1, Byte 2, Byte 3, and Byte 4 is 7-0.

### Little Endian

DWord 1																															
3-1	3-0	2-9	2-8	2-7	2-6	2-5	2-4	2-3	2-2	2-1	2-0	1-9	1-8	1-7	1-6	1-5	1-4	1-3	1-2	1-1	1-0	-9	-8	-7	-6	-5	-4	-3	-2	-1	-0
Word 3																Word 1															
1-5	1-4	1-3	1-2	1-1	1-0	9	8	7	6	5	4	3	2	1	0	1-5	1-4	1-3	1-2	1-1	1-0	-9	-8	-7	-6	-5	-4	-3	-2	-1	-0
Byte 4								Byte 3								Byte 2								Byte 1							
7	6	5	4	3	2	1	0	7	6	5	4	3	2	1	0	7	6	5	4	3	2	-1	-0	-7	-6	-5	-4	-3	-2	-1	-0

### Bits

- The bit range for DWord 1 is 31-0.
- The bit range for Word 3 and Word 1 is 15-0.
- The bit range for Byte 4, Byte 3, Byte 2, and Byte 1 is 7-0.

### Tag Import

The Tag Import dialog specifies the parameters needed for Automatic Tag Database Generation from a Siemens STEP 7 project. Automatic Tag Database Generation is supported for Siemens S7-300 and S7-400 devices only. To generate the tags that have been configured to be imported, open the **Database Creation** tab located in Device Properties and then select **Auto Create**.

#### Note:


Tag import for the Siemens S7-300 and S7-400 devices have been qualified for use with projects created from Siemens Simatic STEP 7 versions 5.3, 5.4, and 5.5.

#### Important:

Tag import for the Siemens TCP/IP Ethernet Driver supports tag names and comments in the native character set as specified by the Windows code page in the Siemens STEP 7 project's language file. A missing, altered, corrupt, or incorrect Siemens STEP 7 language file may cause tag names and comments to import incorrectly. Utilizing the STEP 7 language-neutral option (which allows text to be entered in a different character set than what is used in the STEP 7 language file) may also cause tag names and comments to import incorrectly. The STEP 7 language file can be located in the Global sub-directory of the STEP 7 project root.

#### Note:

Automatic tag generation may result in the display of incorrect characters if the necessary language packs are not installed on the system.



Descriptions of the parameters are as follows:

- **STEP 7 Project File (\*.S7P):** Select the ellipsis button to browse for and select the desired STEP 7 project file (\*.S7P) from which tags will be imported. To clear the configured STEP 7 project, click the **X** button.
- **Program Path:** After specifying the STEP 7 project's \*.S7P file, use this drop-down menu to select the actual PLC program within the project for which tags will be generated.


## Cable Diagrams

### Patch Cable (Straight Through)

TD + 1	OR/WHT	OR/WHT	1 TD +
TD - 2	OR	OR	2 TD -
RD + 3	GRN/WHT	GRN/WHT	3 RD +
4	BLU	BLU	4
5	BLU/WHT	BLU/WHT	5
RD - 6	GRN	GRN	6 RD -
7	BRN/WHT	BRN/WHT	7
8	BRN	BRN	8

RJ45 RJ45

### 10 BaseT



### Crossover Cable

TD + 1	OR/WHT	GRN/WHT	1 TD +
TD - 2	OR	GRN	2 TD -
RD + 3	GRN/WHT	OR/WHT	3 RD +
4	BLU	BLU	4
5	BLU/WHT	BLU/WHT	5
RD - 6	GRN	OR	6 RD -
7	BRN/WHT	BRN/WHT	7
8	BRN	BRN	8

RJ45 RJ45

### 8-pin RJ45

## How To Configure S7-200 Connections in Micro/WIN


Configured connections are accomplished through the Ethernet wizard in Micro/WIN. The following instructions illustrate each step in the Ethernet wizard and also describe any precautions that should be taken. Follow these instructions closely to use configured connections with the Siemens TCP/IP Ethernet Driver correctly.

### Note:


The Micro/WIN software may require an upgrade before the Ethernet wizard is made available.

### Step 1: Launching the Ethernet Wizard


1. In the Micro/WIN main menu, click **Tools | Ethernet Wizard**.



2. Then, click **Next**.



3. Click **Yes** to proceed.




**Note:**

The program must be compiled before the Ethernet wizard can execute. Correct any errors in the program before continuing.


**Step 2: Setting CP243-1 Module Position**

1. Click **Read Modules**.

**Note:**

While it is recommended that the **Read Modules** function be used, this does require that the PLC be connected to the PC either serially or by Ethernet. In either case, the communications parameters for **Micro/WIN** must be properly set for the Read Modules operation to occur.

2. To view the results of Read Modules, select the **Ethernet module**. Click **Next**.




### Step 3: Assigning Module Address

1. Enter the **IP Address**, **Subnet Mask** and **Gateway Address** if applicable. Alternatively, enable **BOOTP** if applicable.
2. Select **Auto Detect Communications** to allow the module to automatically select either **10BaseT** or **100BaseT**. In rare cases where there may be a cable issue that does not allow the module to operate properly at 100BaseT, force the module to use 10BaseT. This will increase the modules' tolerance to a bad Ethernet line.

**Ethernet Wizard**

Module Address

Please select the address to assign to this CP243-1 module. If your network provides a BOOTP server (a service that will automatically assign IP addresses at startup), you may choose to have an IP address automatically assigned.

IP Address:  

Subnet Mask:

Gateway Address:

Allow the BOOTP server to automatically assign an IP address for the module.

Module Connection Type

Specify the communications connection type for this module.

Auto Detect Communications


<Prev Next> Cancel

3. The image shown below contains demonstration values.

**Ethernet Wizard**

Module Address

Please select the address to assign to this CP243-1 module. If your network provides a BOOTP server (a service that will automatically assign IP addresses at startup), you may choose to have an IP address automatically assigned.

IP Address:  

Subnet Mask:

Gateway Address:

Allow the BOOTP server to automatically assign an IP address for the module.

Module Connection Type


Specify the communications connection type for this module.

Auto Detect Communications

<Prev Next> Cancel


### Step 4: Number of Configured Connections

1. Enter the number of desired available connections for this device. If 0 is entered, the only connection available will be the PG connection used by Micro/WIN.

**Note:**

The number of connections selected determines how many simultaneous connections the PLC can support. When intending to have only one OPC server talking to the PLC, set up only one connection. This will ensure the best performance for the OPC server. When intending to have more than one active connection to the PLC, use multiple connections. Keep in mind, however, that the performance of the module will be impacted as each connection is used.

2. The image shown below contains 4 connections.

**Step 5: Configuring Connections**

Each connection is configured individually. For this example, 4 connections have been selected.

**Step 5a: Connection 0**



There are two types of connections, client and server. In a client connection, the device is a client and makes request with servers (other devices). In a server connection, the device is a server and handles requests from clients (such as the OPC server and other devices). The latter is required for communications with the Siemens TCP/IP Ethernet Driver.

1. Select **This is a Server Connection**.

2. From this standpoint, the **CP243-1** is considered the **Server** (local) and the **OPC Server Channel**. The device is considered the **Client (Remote)**.

3. Enter a **Remote TSAP** or accept the default. This will be the **Local TSAP** in the **OPC Server**.

4. **Optional:** Accept all connection requests or limit to a particular remote machine. It is recommended that **Accept all connection requests** be selected. If concerned about device security (or if intending to access this device over the Internet) select a specific IP address. Users must ensure that the OPC server is running on a PC that has a known and fixed IP address.

5. Select **Enable the Keep Alive**.

6. Click **Next Connection**.

**Configure Connections**

You have requested 4 connection(s). For each connection, specify whether the connection should act as a client or server, and configure its associated properties.

Connection 0 (4 connections requested)

This is a Client Connection: Client connections request data transfers between the local PLC and a remote server.

This is a Server Connection: Servers respond to connection requests from remote clients.

Local Properties (Server)

TSAP

10.00

This server will connection with an Operator Panel (OP).

Accept all connection requests.

Accept connection requests from the following clients only:

.....

Remote Properties (Client)

TSAP

10.00

Enable the Keep Alive function for this connection.

Please specify a symbolic name for this client connection. Your program can reference this connection symbolically when initiating data transfers with the remote server.

.....

< Prev Connection      Next Connection >

OK      Cancel

**Step 5b: Connection 1**

1. Select **This is a Server Connection**.

**Configure Connections**

You have requested 4 connection(s). For each connection, specify whether the connection should act as a client or server, and configure its associated properties.

Connection 1 (4 connections requested)

This is a Client Connection: Client connections request data transfers between the local PLC and a remote server.

This is a Server Connection: Servers respond to connection requests from remote clients.

Local Properties (Client)

TSAP

11.00

You may define up to 32 data transfers between this connection and the remote server.

Data Transfers...

Remote Properties (Server)

TSAP

10.00

Specify the IP address of the server for this connection.

0 . 0 . 0 . 0

Enable the Keep Alive function for this connection.

Please specify a symbolic name for this client connection. Your program can reference this connection symbolically when initiating data transfers with the remote server.

Connection0\_1

< Prev Connection    Next Connection >

OK    Cancel

2. Notice the **Local TSAP** automatically incremented to 11.00.
3. Enter a **Remote TSAP** or accept the default. This will be the **Local TSAP** in the **OPC Server**.
4. **Optional: Accept all connection requests.**
5. Select **Enable the Keep Alive**.
6. Click **Next Connection**.

**Configure Connections**

You have requested 4 connection(s). For each connection, specify whether the connection should act as a client or server, and configure its associated properties.

Connection 1 (4 connections requested)

This is a Client Connection: Client connections request data transfers between the local PLC and a remote server.

This is a Server Connection: Servers respond to connection requests from remote clients.

Local Properties (Server)

TSAP

11.00

This server will connection with an Operator Panel (OP).

Accept all connection requests.

Accept connection requests from the following clients only:

Remote Properties (Client)

TSAP

10.00

Enable the Keep Alive function for this connection.

Please specify a symbolic name for this client connection. Your program can reference this connection symbolically when initiating data transfers with the remote server.

< Prev Connection      Next Connection >

OK      Cancel

### Step 5c: Connection 2

1. Select **This is a Server Connection**.

**Configure Connections**

You have requested 4 connection(s). For each connection, specify whether the connection should act as a client or server, and configure its associated properties.

Connection 2 (4 connections requested)

This is a Client Connection: Client connections request data transfers between the local PLC and a remote server.

This is a Server Connection: Servers respond to connection requests from remote clients.

Local Properties (Client)

TSAP

12.00

You may define up to 32 data transfers between this connection and the remote server.

Data Transfers...

Remote Properties (Server)

TSAP

10.00

Specify the IP address of the server for this connection.

0 . 0 . 0 . 0

Enable the Keep Alive function for this connection.

Please specify a symbolic name for this client connection. Your program can reference this connection symbolically when initiating data transfers with the remote server.

Connection0\_2

< Prev Connection    Next Connection >

OK    Cancel

2. Notice the **Local TSAP** automatically incremented to 12.00.
3. Enter a **Remote TSAP** or accept the default. This will be the **Local TSAP** in the **OPC Server**.
4. **Optional: Accept all connection requests.**
5. Select **Enable the Keep Alive**.
6. Click **Next Connection**.

**Configure Connections** [X]

You have requested 4 connection(s). For each connection, specify whether the connection should act as a client or server, and configure its associated properties.

Connection 2 (4 connections requested)

This is a Client Connection: Client connections request data transfers between the local PLC and a remote server.

This is a Server Connection: Servers respond to connection requests from remote clients.

Local Properties (Server)

TSAP  
12.00

This server will connection with an Operator Panel (OP).

Accept all connection requests.

Accept connection requests from the following clients only:

[ ] [IP]

Remote Properties (Client)

TSAP  
10.00

Enable the Keep Alive function for this connection.

Please specify a symbolic name for this client connection. Your program can reference this connection symbolically when initiating data transfers with the remote server.

[ ]

< Prev Connection      Next Connection >

OK      Cancel

**Step 5d: Connection 3**

1. Select **This is a Server Connection....**

**Configure Connections**

You have requested 4 connection(s). For each connection, specify whether the connection should act as a client or server, and configure its associated properties.

Connection 3 (4 connections requested)

This is a Client Connection: Client connections request data transfers between the local PLC and a remote server.

This is a Server Connection: Servers respond to connection requests from remote clients.

Local Properties (Client)

TSAP  
13.00

You may define up to 32 data transfers between this connection and the remote server.

Data Transfers...

Remote Properties (Server)

TSAP  
10.00

Specify the IP address of the server for this connection.

0 . 0 . 0 . 0

Enable the Keep Alive function for this connection.

Please specify a symbolic name for this client connection. Your program can reference this connection symbolically when initiating data transfers with the remote server.

Connection0\_3

< Prev Connection    Next Connection >

OK    Cancel

2. Notice the **Local TSAP** automatically incremented to 13.00.
3. Enter a **Remote TSAP** or accept the default. This will be the Local TSAP in the OPC server.
4. **Optional: Accept all connection requests.**
5. Select **Enable the Keep Alive**.
6. Click **Next Connection**.

**Configure Connections**

You have requested 4 connection(s). For each connection, specify whether the connection should act as a client or server, and configure its associated properties.

Connection 3 (4 connections requested)

This is a Client Connection: Client connections request data transfers between the local PLC and a remote server.  
 This is a Server Connection: Servers respond to connection requests from remote clients.

Local Properties (Server)

TSAP  
13.00

This server will connection with an Operator Panel (OP).  
 Accept all connection requests.

Accept connection requests from the following clients only:

Remote Properties (Client)

TSAP  
10.00

Enable the Keep Alive function for this connection.

Please specify a symbolic name for this client connection. Your program can reference this connection symbolically when initiating data transfers with the remote server.

< Prev Connection    Next Connection >

OK    Cancel

That completes the configuration of the four connections that were selected.

**Note:**


Notice that the **Local TSAP** in the **Connection dialog** was automatically advanced for each connection. This TSAP number will need to be used in the OPC server setup when defining a device as the remote TSAP number.

**Step 6: CRC and Keep Alive Interval**

**Optional:** Enable CRC protection to monitor for accidental configuration corruption.


1. Set the **Keep Alive Interval**. The longer the interval, the longer the connection between the device and the OPC server will exist during idle time. A long Keep Alive Interval may not be desirable if connections are being shared (nonconcurrent). Each remote client will need to wait this amount of time before it will be able to connect with the device once the last connected remote client is finished communications. The 30 second default is suggested.






### Step 7: Memory for Configuration

1. Click **Suggest Address** to let the wizard find the best available location to store the **Ethernet configuration**.




2. The image shown below displays the results.

**Note:**

It is recommended that the Micro/WIN software pick this location for the application. If a CRC was not generated for the configuration data, please take steps to ensure that no other aspect of the PLC program will overwrite this area of memory.


**Step 8: Ethernet Wizard Summary**

1. Click **Finish** or **Prev** to modify the **Configured Connections**.




2. To review what the Ethernet wizard produced, double-click **ETH0\_CTRL** under the **Program Block**. All **TSAPs** configured are listed for future reference. Remember, the **Local TSAP** below is the **Remote TSAP** in the OPC server and the remote TSAP below is the Local TSAP in the OPC server.

3. The image below shows **ETH0\_CTRL**.



4. The image below shows **ETH0\_CFG**.




5. Now that the results of the Ethernet wizard have been confirmed, a connection can be made using the OPC server.

## How To Configure S7-300/400 Connections in STEP 7

to configure the S7-300/400 for communications with the Siemens TCP/IP Ethernet Driver, both the CPU and the Ethernet module will need to be configured as well. To do so, follow the directions below.


1. From the **Simatic Manager**, launch **HW Config** by double-clicking **Hardware** under the **SIMATIC Station**.




2. If this is a new Simatic project, add the necessary modules to the **Rack** in HW Config. For the Siemens TCP/IP Ethernet Driver to communicate with the CPU, there will need to be at least one Ethernet module capable of **S7 Communications**. This may be built into the CPU.

### Configuring an Ethernet Module


1. Right-click on the particular module in the rack and then select **Object Properties**.



2. The dialog should appear as shown below.




3. From the **General** tab, click the **Interface | Properties** button.




4. Specify the **IP** and **Subnet Mask** for this module.
5. To network this module, click **New** under **Subnet**. Next, select the network created and then click **OK**.
6. Return to the HW Config main window.

### Configuring Connections

1. Right-click on the CPU module in the rack and select **Object Properties**.



2. The dialog should appear as shown below.



3. Configure the desired number of **PG/OP** and **PC (S7 Communication)** connections.

Type	Description
PG Communication	Used for program loading, diagnostics
OP Communication	Used for operator control and monitoring
S7 Standard Communication	Communication connections not configured, MPI communications with PUT/GET function blocks
S7 Communication (PC)	Configured connections, data communications

**Note:**

The maximum number of PC connections for the CPU equals the Maximum Number of Connection Resources **minus** the S7 Standard Communication resources **minus** the OP Communication resources **minus** the PG Communication resources. Note that the Maximum Number of Connection Resources is based on the CPU/version/firmware.

In the example shown above, there are six S7 communication (PC) connections available ( $12 - 4 - 1 - 1 = 6$ ). Likewise, the number of PG and OP connections can be increased using the same concept.

If the **Device returned protocol [Class=0x83, Code=0x04]** error is encountered, increase the number of S7 Standard Communication connections, thereby decreasing the number of S7 Communication connections.

4. After the connections have been configured, click **OK**. Next, in the main HW Config window click **Station | Save and Compile**.

5. Click **PLC | Download** to commit to the changes.


## How To Configure S7-1200 Connections with the Totally Integrated Automation (TIA) Portal

to configure the S7-1200 for communications with the Siemens TCP/IP Ethernet Driver, an online connection is required between the programming device and the target system. Users may have to configure the programming device to talk to the target system. For more information, follow the instructions below.

**Note:**

For new Simatic projects, refer to the PLC's documentation for information on the default IP address settings.


1. Start the TIA Portal. In the Portal View, click **Create new project**.




2. Next, select the **Online & Diagnostics** tab and then click **Accessible Devices**.



3. Select the appropriate PG/PC interface. This will prompt the TIA to scan the network for the device.




4. Once the scan is complete, select the device and then click **Show**. This will invoke the Project View.
5. In the project tree, locate the IP address and then open **Online & Diagnostics**.
6. Next, double-click **Online & Diagnostics** to invoke **Online Access**.
7. Select **Functions** and then click **Assign IP Address**.




8. Enter the communication settings and click **Assign IP Address**.

**Note:** The device is now ready to be configured.


9. Return to the Portal View and then select the **Device & Networks** tab. Then, click **Add new device**.



10. Next, select the device's configuration and then click **Add device**. This will invoke the Project View, where the device's hardware can be further configured.



11. Once finished, view the project tree. Locate **Program Blocks** and **PLC Tags** and then configure the addresses that will be used in the PLC project.



**Note:** The device is now configured and can be placed in Run Mode for communications.


## How To Configure S7-1500 Connections

The S7-1500 controller has an embedded Ethernet port that supports S7 communications over the Ethernet protocol. It must be configured to allow access from the server, however. For more information, refer to the instructions below.

1. To start, open the PLC project in the S7 AI Portal software.
2. Next, open **PLC Properties**.
3. In the **General** tab, select **Protection**. Then, ensure that **Full access (no protection)** is enabled.

**Note:** At this time, the Siemens TCP/IP Ethernet Driver does not support the use of a password.

4. Next, check **Permit access with PUT/GET communication from remote partner**. Then, save the settings.




- In the server, create a new channel. In **Device Driver**, select **Siemens TCP/IP Ethernet Driver** from the drop-down list. Continue through the channel wizard, specifying channel properties as needed. Then, click **Finish**.
- Next, create a new device. In **Model**, select **S7-1500** from the **Device Model** drop-down list. Continue through the device wizard, specifying device properties as needed. Then, click **Finish**.

**Note:** The controller Protection settings are directly related to the device returning protocol error [Class=0x81, Code=0x04]. If this error occurs, the controller's memory (such as the Simatic memory card) may need to be reset. Once the controller's memory is reset, downloading the S7 project to the controller should not prompt for a password.

## Optimizing Siemens TCP/IP Ethernet Communications


The Siemens TCP/IP Ethernet Driver was designed to provide the best performance with the least amount of impact on the system's overall performance. While the Siemens TCP/IP Ethernet Driver is fast, there are a couple of guidelines that can be used to optimize the application and gain maximum performance.

This server refers to communications protocols like Siemens TCP/IP Ethernet as a channel. Each channel defined in the application represents a separate path of execution in the server. Once a channel has been defined, a series of devices can then be defined under that channel. Each of these devices represents a single Siemens TCP/IP Ethernet controller from which data will be collected. Although this approach to defining the application provides a high level of performance, it does not take full advantage of the Siemens TCP/IP Ethernet Driver or the network. An example of how the application may appear when configured using a single channel is shown below.



Each device appears under a single Siemens TCP/IP Ethernet channel. In this configuration, the driver must move from one device to the next as quickly as possible to gather information at an effective rate. As more devices are added or more information is requested from a single device, the overall update rate begins to suffer.

If the Siemens TCP/IP Ethernet Driver could only define one channel, then the example above would be the only option available; however, the Siemens TCP/IP Ethernet Driver can define up to 256 channels. Using multiple channels distributes the data collection workload by simultaneously issuing multiple requests to the network. An example of how the same application may appear when configured using multiple channels is shown below.



Each device has now been defined under its own channel. In this new configuration, a single path of execution is dedicated to the task of gathering data from each device.

The performance will improve even if the application has more than 256 devices. While 256 or fewer devices may be ideal, the application will still benefit from additional channels. Although spreading the device load across all channels will cause the server to move from device to device again, it can now do so with far less devices to process on a single channel.

**Important:** Although the OPC server limits the number of channels to 256, the device ultimately determines the number of allowed connections. This constraint comes from the fact that some devices cannot support 256 connections. For these devices, the maximum number of channels defined should equal the maximum number of connections allowed. For devices that support more than 256 connections, the maximum 256 channels should be defined, with devices spread evenly over these 256 channels. For more information on device connections, refer to [Link Settings](#).

## Data Types Description

---

Data Type	Description
Boolean	Single bit
Byte	Unsigned 8-bit value
Char	Signed 8-bit value
Word	Unsigned 16-bit value bit 0 is the low bit bit 15 is the high bit
Short	Signed 16-bit value bit 0 is the low bit bit 14 is the high bit bit 15 is the sign bit
BCD	Two byte packed BCD Value range is 0-9999. Behavior is undefined for values beyond this range
DWord	Unsigned 32-bit value bit 0 is the low bit bit 31 is the high bit
Long	Signed 32-bit value bit 0 is the low bit bit 30 is the high bit bit 31 is the sign bit
LBCD	Four byte packed BCD Value range is 0-99999999. Behavior is undefined for values beyond this range
Float	32-bit floating point value The driver interprets two consecutive registers as a floating-point value by making the second register the high word and the first register the low word.
Date	64-bit floating-point value
String	Null-terminated ASCII string*

\*The Data Block subtype, String, is a NULL padded ASCII string.

## Address Descriptions

Address specifications vary depending on the model in use. Select a link from the following list to obtain information for the model of interest.

[S7-200 Address Descriptions](#)

[S7-300 Address Descriptions](#)

[S7-400 Address Descriptions](#)

[S7-1200 Address Descriptions](#)

[S7-1500 Address Descriptions](#)

[NetLink: S7-300 Address Descriptions](#)

[NetLink: S7-400 Address Descriptions](#)

[Internal Tags](#)

## S7-200 Address Descriptions

The default data types for dynamically defined tags are shown in **bold**.

Address Type	Range	Type	Access
Discrete Inputs (IEC)	I0.b-I65535.b .b is Bit Number 0-7	<b>Boolean</b>	Read/Write
	IB0-IB65535	<b>Byte</b> , Char, String**	Read/Write
	IW0-IW65534 ID0-ID65532	<b>Word</b> , Short, BCD <b>DWord</b> , Long, LBCD, Float	Read/Write Read/Write
Discrete Inputs (SIMATIC)	E0.b-E65535.b .b is Bit Number 0-7	<b>Boolean</b>	Read/Write
	EB0-EB65535**	<b>Byte</b> , Char, String**	Read/Write
	EW0-EW65534 ED0-ED65532	<b>Word</b> , Short, BCD <b>DWord</b> , Long, LBCD, Float	Read/Write Read/Write
<b>Note:</b> I and E access the same memory area.			
Discrete Outputs (IEC)	Q0.b-Q65535.b .b is Bit Number 0-7	<b>Boolean</b>	Read/Write
	QB0-QB65535	<b>Byte</b> , Char, String**	Read/Write
	QW0-QW65534 QD0-QD65532	<b>Word</b> , Short, BCD <b>DWord</b> , Long, LBCD, Float	Read/Write Read/Write
Discrete Outputs (SIMATIC)	A0.b-A65535.b .b is Bit Number 0-7	<b>Boolean</b>	Read/Write
	AB0-AB65535	<b>Byte</b> , Char, String**	Read/Write
	AW0-AW65534 AD0-AD65532	<b>Word</b> , Short, BCD <b>DWord</b> , Long, LBCD, Float	Read/Write Read/Write
<b>Note:</b> Q and A access the same memory area.			
Analog Inputs ( <b>IEC</b> )	AI0-AI65534*** AIW0-AIW65534	<b>Word</b> , Short	Read Only
Analog Inputs (SIMATIC)	AE0-AE65534*** AEW0-AEW65534	<b>Word</b> , Short	Read Only
<b>Note:</b> AI and AE access the same memory area.			
Analog Outputs (IEC)	AQ0-AQ65534*** AQW0-AQW65534	<b>Word</b> , Short	Read/Write
Analog Outputs (SIMATIC)	AA0-AA65534*** AAW0-AAW65534	<b>Word</b> , Short	Read/Write
<b>Note:</b> AQ and AA access the same memory area.			
Internal Memory	M0.b-M65535.b .b is Bit Number 0-7	<b>Boolean</b>	Read/Write

	MB0-MB65535 MW0-MW65534 MD0-MD65532	<b>Byte</b> , Char, String** <b>Word</b> , Short, BCD <b>DWord</b> , Long, LBCD, Float	Read/Write Read/Write Read/Write
Special Memory (Bytes 0-29 are Read Only)	SM0.b-SM65535.b .b is Bit Number 0-7	Boolean	Read/Write
	SMB0-SMB65535 SMW0-SMW65534 SMD0-SMD65532	<b>Byte</b> , Char, String** <b>Word</b> , Short, BCD <b>DWord</b> , Long, LBCD, Float	Read/Write Read/Write Read/Write
Sequence Control Relay (SCR)	S0.b-S65535.b .b is Bit Number 0-7	Boolean	Read/Write
	SB0-SB65535 SW0-SW65534 SD0-SD65532	<b>Byte</b> , Char, String** <b>Word</b> , Short, BCD <b>DWord</b> , Long, LBCD, Float	Read/Write Read/Write Read/Write
Variable Memory	V0.b-V65535.b .b is Bit Number 0-7	Boolean	Read/Write
	VB0-VB65535 VW0-VW65535 VD0-VD65535	<b>Byte</b> , Char, String** <b>Word</b> , Short, BCD <b>DWord</b> , Long, LBCD, Float	Read/Write Read/Write Read/Write
Timer Current Values	T0-T65535*	DWord, <b>Long</b>	Read/Write
Timer Status Bit	T0-T65535*	Boolean	Read Only
Counter Current Values (IEC)	C0-C65535*	<b>Word</b> , Short	Read/Write
Counter Status Bit (IEC)	C0-C65535*	Boolean	Read Only
Counter Current Values (SIMATIC)	Z0-Z65535*	<b>Word</b> , Short	Read/Write
Counter Status Bit (SIMATIC)	Z0-Z65535*	Boolean	Read Only
<b>Note:</b> C and Z access the same memory area.			
High-Speed Counter	HC0-HC65535*	DWord, <b>Long</b>	Read Only

\*These memory types/subtypes do not support arrays.

\*\*Byte memory types (MB) support strings. The syntax for strings is <address>.<length> where 0 < length <= 212.

\*\*\*For Analog Inputs and Outputs, the address must be even (AI0, AI2, AI4, and so forth).

#### Notes:

1. All offsets for memory types I, Q, M, S, and SM represent a byte starting location within the specified memory type.
2. Use caution when modifying Word, Short, DWord, and Long types. For I, Q, and F, each address starts at a byte offset within the device. Therefore, Words MW0 and MW1 overlap at byte 1. Writing to MW0 will also modify the value held in MW1. Similarly, DWord, and Long types can also overlap. It is recommended that these memory types be used so that overlapping does not occur. For example, DWord MD0, MD4, MD8, and so on can be used to prevent overlapping bytes.

#### Arrays

All memory types/subtypes with the exception of those marked with an asterisk support arrays. The valid syntax for declaring an array is as follows:

```
<address>[rows][cols]
<address>.rows.cols
<address>,rows,cols
<address>_rows_cols
```

#### Note:

If no rows are specified, a row count of 1 is assumed.

For Word, Short, and BCD arrays, the base address + (rows \* cols \* 2) cannot exceed 65536. Keep in mind that the elements of the array are words, located on a word boundary. For example, IW0[4] would return IW0, IW2, IW4, and IW6.



For Float, DWord, Long, and Long BCD arrays, the base address + (*rows \* cols \* 4*) cannot exceed 65536. Keep in mind that the elements of the array are DWord, located on a DWord boundary. For example, ID0[4] will return ID0, ID4, ID8, and ID12.

For all arrays, the total number of bytes being requested cannot exceed the internal block size of 218 bytes.

## **S7-300 Address Descriptions**

---

### **Standard Support**

[S7-300/400/1200/1500 Item Syntax](#)

[Internal Tags](#)

### **Third-Party Support**

For users familiar with the following applications, limited addressing support is available.

[Applicom Direct-Link Item Syntax](#)

[INAT OPC-Server TCIP1H1 Item Syntax](#)

[Siemens Simatic Net Item Syntax](#)

[Siemens STEP 7 Item Syntax](#)

[Softing S7/S5 OPC Server Item Syntax](#)

### **Legacy Support**

[Legacy S7-300/400 Item Syntax](#)

#### **Note:**

All brand and product names are trademarks, registered trademarks, or service marks of their respective holders.

## **S7-400 Address Descriptions**

---

### **Standard Support**

[S7-300/400/1200/1500 Item Syntax](#)

[Internal Tags](#)

### **Third-Party Support**

For users familiar with the following applications, limited addressing support is available.

[Applicom Direct-Link Item Syntax](#)

[INAT OPC-Server TCIP1H1 Item Syntax](#)

[Siemens Simatic Net Item Syntax](#)

[Siemens STEP 7 Item Syntax](#)

[Softing S7/S5 OPC Server Item Syntax](#)

### **Legacy Support**

[Legacy S7-300/400 Item Syntax](#)

#### **Note:**

All brand and product names are trademarks, registered trademarks, or service marks of their respective holders.

## **S7-1200 Address Descriptions**

---

### **Standard Support**

[S7-300/400/1200/1500 Item Syntax](#)

[Internal Tags](#)

### **Third-Party Support**

For users familiar with the following applications, limited addressing support is available.

[Applicom Direct-Link Item Syntax](#)

[INAT OPC-Server TCIP1H1 Item Syntax](#)

[Siemens Simatic Net Item Syntax](#)

[Siemens STEP 7 Item Syntax](#)

[Softing S7/S5 OPC Server Item Syntax](#)

### **Legacy Support**

[Legacy S7-300/400 Item Syntax](#)

**Note:**

All brand and product names are trademarks, registered trademarks, or service marks of their respective holders.

**S7-1500 Address Descriptions**

---

**Standard Support**

[S7-300/400/1200/1500 Item Syntax](#)

[Internal Tags](#)

**Third-Party Support**

For users familiar with the following applications, limited addressing support is available.

[Applicom Direct-Link Item Syntax](#)

[INAT OPC-Server TCIP1H1 Item Syntax](#)

[Siemens Simatic Net Item Syntax](#)

[Siemens STEP 7 Item Syntax](#)

[Softing S7/S5 OPC Server Item Syntax](#)

**Legacy Support**

[Legacy S7-300/400 Item Syntax](#)

**Note:**

All brand and product names are trademarks, registered trademarks, or service marks of their respective holders.

**NetLink: S7-300 Address Descriptions**

---

**Standard Support**

[S7-300/400/1200/1500 Item Syntax](#)

**Third-Party Support**

For users familiar with the following applications, limited addressing support is available.

[Applicom Direct-Link Item Syntax](#)

[INAT OPC-Server TCIP1H1 Item Syntax](#)

[Siemens Simatic Net Item Syntax](#)

[Siemens STEP 7 Item Syntax](#)

[Softing S7/S5 OPC Server Item Syntax](#)

**Legacy Support**

[Legacy S7-300/400 Item Syntax](#)

**Note:**

All brand and product names are trademarks, registered trademarks, or service marks of their respective holders

**NetLink: S7-400 Address Descriptions**

---

**Standard Support**

[S7-300/400/1200/1500 Item Syntax](#)

**Third-Party Support**

For users familiar with the following applications, limited addressing support is available.

[Applicom Direct-Link Item Syntax](#)

[INAT OPC-Server TCIP1H1 Item Syntax](#)

[Siemens Simatic Net Item Syntax](#)

[Siemens STEP 7 Item Syntax](#)

[Softing S7/S5 OPC Server Item Syntax](#)

**Legacy Support**

[Legacy S7-300/400 Item Syntax](#)

**Note:**

All brand and product names are trademarks, registered trademarks, or service marks of their respective holders

## Internal Tags

Although the following internal tags are not visible in the server configuration, they can be browsed by the OPC client. They can be found under the <Channel Name>.<Device Name>.\_InternalTags group. If the OPC client does not support browsing, or if a non-OPC client is being used, the tags can be created dynamically and statically by using the addresses given below.

### Note:

The tags listed in the following table are valid for the S7-300, S7-400, S7-1200, and S7-1500 device models. The default data types are shown in **bold**.

Device Address	Description	Range	Data Type	Access
_RACK	Number of the rack in which the CPU of interest resides.  On changing this device property, the connection with the CPU is re-established.	0-7	<b>Byte</b> , Short	Read/Write
_SLOT	Number of the slot in which the CPU of interest resides.  On changing this device property, the connection with the CPU is re-established.	2-31	<b>Byte</b> , Short	Read/Write

## Standard S7-300/400/1200/1500 Item Syntax

### Address Syntax

#### Input, Output, Peripheral, Flag Memory Types

<memory type><S7 data type><address>  
 <memory type><S7 data type><address><.bit>  
 <memory type><S7 data type><address><.string length>\*  
 <memory type><S7 data type><address><[row][>col]>

#### Timer and Counter Memory Types

<memory type><address>

#### DB Memory Type

DB<num>,<S7 data type><address>  
 DB<num>,<S7 data type><address><.bit>  
 DB<num>,<S7 data type><address><.string length>\*  
 DB<num>,<S7 data type><address><[row][col]>

where <num> ranges from 1 to 65535.

\*Applies to S7 data types that support string. String length can vary from 0<n<= 212, with the exception of S7 data type string (which can vary from 0<n<= 210).

### See Also:

[Examples](#) and [String Support](#).

## Memory Types

Memory Type	Description	Address Range	Data Type	Access
I E	Inputs	Dependent on S7 Data Type		Read/Write
Q A	Outputs			Read/Write
PI PE	Peripheral Inputs			Read Only
PQ PA	Peripheral Outputs			Read/Write
M F	Flag Memory			Read/Write
DB	Data Blocks			Read/Write
T	Timers			T0-T65535
C Z	Counters	C0-C65535 Z0-Z65535	<b>Word</b> , Short	Read/Write

See Also: [Examples](#)

### S7 Data Types

The S7 data type is used to coerce the data type for a tag. It does not apply to Timers and Counters. The default data types are shown in **bold**.

S7 Data Type	Description	Address Range	Data Type
B Byte	Unsigned Byte	B0-B65535 BYTE0- BYTE65535  B0.b-B65535.b BYTE0.b- BYTE65535.b .b is Bit Number 0-7  B0.n-B65535.n BYTE0.n- BYTE65535.n .n is string length. 0 < n <= 212.	<b>Byte</b> , Char  Boolean  String*
C Char	Signed Byte	C0-C65535 CHAR0- CHAR65535  C0.b-C65535.b CHAR0.b- CHAR65535.b .b is Bit Number 0-7  C0.n-C65535.n CHAR0.n- CHAR65535.n .n is string length. 0 < n <= 212.	<b>Byte</b> , <b>Char</b>  Boolean  String*
D DWORD	Unsigned Double Word	D0-D65532 DWORD0- DWORD65532  D0.b-D65532.b DWORD0.b- DWORD65532.b .b is Bit Number 0-31	<b>DWord</b> , Long, LBCD, Float  Boolean
DATE	S7 Date  Stored as WORD in steps of 1 day since January 1, 1990.  Displayed as string format "yyyy-mm-dd" with range "1990-01-01" to "2168-12-31".  Read/Write	DATE0- DATE65534	<b>String</b>
DI DINT	Signed Double Word	DI0-DI65532 DINT0- DINT65532  DI0.b-	DWord, <b>Long</b> , LBCD, Float

		DI65532.b DINT0.b- DINT65532.b .b is Bit Number 0-31	Boolean
DT	S7 Date_And_Time  Complex data type stored with 8 bytes as follows:  0 year, 1 month, 2 days, 3 hours, 4 minutes, 5 seconds, 6 two most significant digits of MSEC, 7 (4MSB) two least significant digits of MSEC, 7 (4LSB) day of week (1=Sunday).  Displayed as string format "m/d/y h:mm:ss <AM/PM>" with range "1/1/1990 0:00:00 AM" to "12/31/2089 23:59:59 PM".  Displayed as date format "yyyy-mm-ddThh:mm:ss.hhh" with range "1990-01-01T00:00:00.000" to "2089-12-31T23:59:59.998".  Read Only.	DT0-DT65528	<b>String</b> , Date
I INT	Signed Word	IO-I65534 INT0-INT65534  IO.b-I65534.b INT0.b- INT65534.b .b is Bit Number 0-15	Word, <b>Short</b> , BCD  Boolean
REAL	IEEE Float	REAL0- REAL65532	<b>Float</b>
String	S7 String	STRING0.n- STRING65532.n .n is string length. 0<n<= 210.	<b>String</b>
T TIME	S7 TIME.  Stored as DWORD in steps of milliseconds.  Displayed as string format "+/-ddD_hhH_mmM_ssS_hhhMS" with range "-24D_20H_31M_23S_648MS" to "24D_20H_31M_23S_647MS".  Read/Write.	T0-T65532 TIME0- TIME65532	<b>String</b>
TOD	S7 Time_Of_Day.  Stored as DWORD, representing milliseconds since midnight. Displayed as string format "h:m:s.mmm" with range "0:0:0.0" to "23:59:59.999".  Read/Write.	TOD0- TOD65532	<b>String</b>
W Word	Unsigned Word	W0-W65534 WORD0- WORD65534  W0.b-W65534.b WORD0.b- WORD65534.b .b is Bit Number 0-15	<b>Word</b> , Short, BCD  Boolean
X	Bit	X0.b-X65534.b .b is Bit Number	<b>Boolean</b>

0-15

\*These are raw strings that differ in structure and usage from the STEP 7 string data type.

**Note:**

Use caution when modifying Word, Short, DWord, and Long type as each address starts at a byte offset within the device. Therefore, Words MW0 and MW1 overlap at byte 1. Writing to MW0 will also modify the value held in MW1. Similarly, DWord, and Long types can also overlap. It is recommended that these memory types be used so that overlapping does not occur. For example, DWord MD0, MD4, MD8, and so on can be used to prevent overlapping bytes.

**See Also:** [Examples](#)

**String Support****Raw Strings**

For an address DBx,By.n @ string, string values read and written are stored at byte offset y.

y	y+1	y+2	...	y+n-1
''	''	''	...	''

Raw strings are null terminated. If the maximum string length is 10 and 3 characters are written, the fourth character is set to NULL, while characters 5-10 are left untouched.

**String Support**

The string subtype follows the STEP 7 string data type definition. The syntax for the string S7 data type is *STRINGy.n* where y is the Byte offset, and n is the maximum string length. If n is not specified, the maximum string length will be 210 characters. String values read and written are stored at byte offset y+2 in data block x. The actual string length gets updated with every write based on the string length of the string being written.

y	y+1	y+2	y+3	y+4	...	y+2+n-1
maximum string length (n)	actual string length	''	''	''	...	''

**Note:**

String strings are NULL padded. If the maximum string length is 10 and 3 characters are written, characters 4-10 are set to NULL.

**Hex Strings**

The HEXSTRING subtype is specific to the Siemens TCP/IP Ethernet Driver. The syntax for the HEXSTRING subtype is *HEXSTRINGy.n*, where y is the byte offset and n is the length. The n value must be specified in the range of 1 through 212. String is the only valid data type for a HEXSTRING tag.

The value assigned to a HEXSTRING must be an even number of characters. There is no padding, so the entire string must be specified. For example, tag HexStr defined as DB1,STRING0.10 uses 10 bytes of storage and has a display length of 20. To assign a value, the string must be 20 characters long and contain only valid hexadecimal characters. An example valid hex string for this tag is "56657273696f6E353137".

**Array Support**

The [rows][cols] notation is appended to an address to specify an array (such as MW0[2][5]). If no rows are specified, row count of 1 is assumed. Boolean arrays and string arrays are not supported.

For Word, Short, and BCD arrays, the base address + (rows \* cols \* 2) cannot exceed 65536. Keep in mind that the elements of the array are words, located on a word boundary. For example, IW0[4] would return IW0, IW2, IW4, and IW6.

For Float, DWord, Long, and Long BCD arrays, the base address + (rows \* cols \* 4) cannot exceed 65536. Keep in mind that the elements of the array are DWord, located on a DWord boundary. For example, ID0[4] will return ID0, ID4, ID8, ID12.

For all arrays, the total number of bytes being requested cannot exceed the internal block size of 212 bytes.

**Timers**

The Siemens TCP/IP Ethernet Driver automatically scales T values based on the Siemens S5 time format. Timer data is stored as a Word in the PLC but scaled to a DWord in the driver. The value returned will already be scaled using the appropriate Siemens time base. As a result, the values are always returned as a count of milliseconds.

When writing to T memory, the Siemens time base will also be applied. To assign a value to a timer in the controller, write the desired value as a count of milliseconds to the appropriate timer.

### Counters

The value returned for C memory will automatically be converted to a BCD value.

### Examples

S7 Data Type	Data Type	Input	Flags	Data Blocks
B Byte	Byte	IB0 IBYTE0	MB0 MBYTE0	DB1,B0 DB1,BYTE0
	Boolean	IB0.7 IBYTE0.7	MB0.7 MBYTE0.7	DB1,B0.7 DB1,BYTE0.7
	String	IB0.64 IBYTE0.64	MB0.64 MBYTE0.64	DB1,B0.64 DB1,BYTE0.64
	Array	IB0[2][5] IBYTE0[2][5]	MB0[2][5] MBYTE0[2][5]	DB1,B0[2][5] DB1,BYTE0[2][5]
C Char	Char	IC0 ICHAR0	MC0 MCHAR0	DB1,C0 DB1,CHAR0
	Boolean	IC0.7 ICHAR0.7	MC0.7 MCHAR0.7	DB1,C0.7 DB1,CHAR0.7
	String	IC0.64 ICHAR0.64	MC0.64 MCHAR0.64	DB1,C0.64 DB1,CHAR0.64
	Array	IC0[10] ICHAR0[10]	MC0[10] MCHAR0[10]	DB1,C0[10] DB1,CHAR0[10]
D DWORD	DWord	ID0 IDWORD0	MD0 MDWORD0	DB1,D0 DB1,DWORD0
	Boolean	ID0.31 IDWORD0.31	MD0.31 MDWORD0.31	DB1,D0.31 DB1,DWORD0.31
	Array	ID0[10] IDWORD0[10]	MD0[10] MDWORD0[10]	DB1,D0[10] DB1,DWORD0[10]
DATE	String	IDATE0	MDATE0	DB1,DATE0
DI DINT	Long	IDIO IDINT0	MDIO MDINT0	DB1,DI0 DB1,DINT0
	Boolean	IDIO.31 IDINT0.31	MDIO.31 MDINT0.31	DB1,DI0.31 DB1,DINT0.31
	Array	IDIO[4][3] IDINT0[4][3]	MDIO[4][3] MDINT0[4][3]	DB1,DI0[4][3] DB1,DINT0[4][3]
DT	String Date	IDT0 IDT8	MDT0 MDT8	DB1,DT0 DB1,DT8
I INT	Short	IIO IINT0	MIO MINT0	DB1,I0 DB1,INT0
	Boolean	IIO.15 IINT0.15	MIO.15 MINT0.15	DB1,I0.15 DB1,INT0.15
	Array	IIO[5][2] IINT0[5][2]	MIO[5][2] MINT0[5][2]	DB1,I0[5][2] DB1,INT0[5][2]
REAL	Float	IREAL0	MREAL0	DB1,REAL0
	Array	IREAL0[10]	MREAL0[10]	DB1,REAL0[10]
String	String	ISTRING0.10	MSTRING0.10	DB1,STRING0.10
TOD	String	ITOD0	MTOD0	DB1,TOD0
T	String	IT0	MT0	DB1,T0

TIME		ITIME4	MTIME4	DB1,TIME4
W Word	Word	IW0 IWORD0	MW0 MWORD0	DB1,W0 DB1,WORD0
	Boolean	IW0.15 IWORD0.15	MW0.15 MWORD0.15	DB1,W0.15 DB1,WORD0.15
	Array	IW0[10] IWORD0[10]	MW0[10] MWORD0[10]	DB1,W0[10] DB1,WORD0[10]
X	Boolean	IX0.7 IX0[10]	MX0.7 MX0[10]	DB1,X0.7 DB1,X0[10]

### Applicom Direct-Link Item Syntax

The following support for the Applicom Direct-Link OPC server is considered to be limited. Care must be taken because the data type for a given S7 data type/suffix may differ from the data type for the same S7 data type/suffix in the specified product. Applicom ASCII strings are not supported by this driver. The following information is intended to be a guideline for users that are already familiar with and/or prefer the syntax of the specified product. For preferred item syntax, refer to [Standard S7-300/400/1200/1500 Item Syntax](#).

#### Address Syntax

##### Input, Output, Peripheral, Flag Memory Types

<memory type>.<S7 data type> <address>[<Data Type suffix>] [<Byte Switching suffix>]  
<memory type>.<S7 data type> <address>[<Data Type suffix>]<\_row\_col>

##### Timer and Counter Memory Types

<memory type> <address>

#### DB Memory Type

DB<num>.<S7 data type> <address>[<Data Type suffix>][<Byte Switching suffix>]  
DB<num>.<S7 data type> <address>[<Data Type suffix>]<\_row\_col>

Where <num> ranges from 1 to 65535.

See Also: [Examples](#)

#### Memory Types

Memory Type	Description	Address Range	Data Type	Access
I E	Inputs	Dependent on S7 Data Type		Read/Write
Q A	Outputs			Read/Write
PI PE	Peripheral Inputs			Read Only
PQ PA	Peripheral Outputs			Read/Write
M F	Flag Memory			Read/Write
DB	Data Blocks			Read/Write
T	Timers			T0-T65535
C Z	Counters	C0-C65535 Z0-Z65535	<b>Word</b> , Short	Read/Write

See Also: [Examples](#)

#### S7 Data Types

The S7 data type is used to coerce the data type for a tag. It does not apply to Timers and Counters. The default data types are shown in **bold**. Suffixes are not required.

Data Type	Description	Address Range	Data Type	Suffix	Data Type w/ Suffix
None* DBX**	Bit	0.b-65534.b DBX0.b-	<b>Boolean</b>		



		DBX65534.b			
		.b is Bit Number 0-15			
B DBB**	Unsigned Byte	B0-B65535 DBB0-DBB65535	<b>Byte</b> , Char		
W DBW**	Unsigned Word	W0-W65534 DBW0-DBW65534	<b>Word</b> , Short, BCD		
D DBD**	Unsigned Double Word	D0-D65532 DBD0-DBD65532	<b>DWord</b> , Long, LBCD, Float	F	Float

\*No S7 data type specified. Applies to non-DB memory types only.

\*\*Applies to DB memory types only.

See Also: [Examples](#)

### Data Type Suffixes

Suffix	Description	Data Type
F	32-bit IEEE floating point value	Float

### Byte Switching Suffixes

These suffixes are used to switch the bytes that compose data of type 16-bit Word, 32-bit DWord, or 32-bit Float. The switching is applied after the device-level addressing option for byte Order is applied. For more information, refer to [Addressing Options](#).

Byte Switching Suffixes can be used with all memory types except Timers and Counters (T, C, and Z) and Peripheral Inputs and Outputs (PI, PE, PQ, and PA). For information on the various types of switching that depend on the suffix and data type of the item, refer to the table below.

Suffix	16-Bit Data Types (Word, Short, BCD)	32-Bit Data Types (DWord, Long, LBCD, Float)
_X1	O1 O2 -> O2 O1 (byte switching)	O1 O2 O3 O4 -> O4 O3 O2 O1 (byte switching)
_X2	O1 O2 -> O2 O1 (byte switching)	O1 O2 O3 O4 -> O3 O4 O1 O2 (Word switching)
_X3	O1 O2 -> O2 O1 (byte switching)	O1 O2 O3 O4 -> O2 O1 O4 O3 (Switching bytes in the words)

### Array Support

The `<.array size>` notation is appended to an address to specify an array (such as "MW0.10"). Boolean arrays and string arrays are not supported.

### Examples

S7 Data Type	Data Type	Input	Flags	Data Blocks
None DBX	Boolean Boolean	I0.7 ----	M0.7 ----	---- DB1.DBX0.7
B DBB	Byte  Array	IB0 ---- IB0_2_5 ----	MB0 ---- MB0_2_5 ----	---- DB1.DBB0 ---- DB1.DBB0_2_5
W DBW	Word  Array	IW0 ---- IW0_X1 ---- IW0_10 ----	MW0 ---- MW0_X2 ---- MW0_10 ----	---- DB1.DBW0 DB1.DBW0_X3 ---- DB1.DBW0_10
D DBD	DWord  Float (F)	ID0 ---- ID0_X1 ---- ID0F ID0F_X1	MD0 ---- MD0_X2 ---- MD0F MD0F_X2	---- DB1.DBD0 DB1.DBD0_X3 ---- DB1.DBD0F DB1.DBD0F_X3

	Array	ID0_4_3 ----	MD0_4_3 ----	---- DB1.DBDOF_4_3
--	-------	-----------------	-----------------	-----------------------

**Note:**

All brand and product names are trademarks, registered trademarks, or service marks of their respective holders.

**INAT OPC Server TCIPH1 Item Syntax**

The following support for the INAT OPC Server TCIPH1 (V1.22 and up) is considered to be limited. Care must be taken as the data type for a given S7 data type/suffix may differ from the data type for the same S7 data type/suffix in the specified product. S7 data type and suffixes not included below are not supported by this driver. The following information is intended to be a guideline for users that are already familiar with and/or prefer the syntax of the specified product. For preferred item syntax, refer to [Standard S7-300/400/1200/1500 Item Syntax](#).

**Address Syntax****Input, Output, Peripheral, Flag Memory Types**

<memory type> <S7 data type> <address> [<suffix>]

<memory type> <S7 data type> <address> <.string length>\*

<memory type> <S7 data type> <address> <.array size> [<suffix>]

**Timer and Counter Memory Types**

<memory type> <address>

**DB Memory Type**

DB<num>.<S7 data type> <address> [<suffix>]

DB<num>.<S7 data type> <address> <.string length>\*

DB<num>.<S7 data type> <address> <.array size> [<suffix>]

Where <num> ranges from 1 to 65535.

\*Applies to S7 data types that support string.

See Also: [Examples](#)

**Memory Types**

Memory Type	Description	Address Range	Data Type	Access
I E	Inputs	Dependent on S7 Data Type		Read/Write
Q A	Outputs			Read/Write
PI PE	Peripheral Inputs			Read Only
PQ PA	Peripheral Outputs			Read/Write
M F	Flag Memory			Read/Write
DB	Data Blocks			Read/Write
T	Timers	T0-T65535	DWord, <b>Long</b>	Read/Write
C Z	Counters	C0-C65535 Z0-Z65535	<b>Word</b> , Short	Read/Write

See Also: [Examples](#)

**S7 Data Types**

The S7 data type is used to coerce the data type for a tag. It does not apply to Timers and Counters. Default data types are shown in **bold**. A suffix is not required.

Data Type	Description	Address Range	Data Type	Suffix	Data Type w/ Suffix
X	Bit	X0.b-X65534.b .b is Bit Number 0-15	<b>Boolean</b>		
B	Unsigned Byte	B0-B65535	<b>Byte</b> , Char	KF	Char

Byte		BYTE0-BYTE65535			
W Word	Unsigned Word	W0-W65534 WORD0-WORD65534	<b>Word</b> , Short, BCD	BCD KF	BCD Short
I INT	Signed Word	I0-I65534 INT0-INT65534	Word, <b>Short</b> , BCD	BCD	BCD
D DWORD	Unsigned Double Word	D0-D65532 DWORD0-DWORD65532	<b>DWord</b> , Long, LBCD, Float	BCD IEEE KF	LBCD Float Long
DI DINT	Signed Double Word	DI0-DI65532 DINT0-DINT65532	DWord, <b>Long</b> , LBCD, Float	BCD IEEE	LBCD Float
R REAL	IEEE Float	R0-R65532 REAL0-REAL65532	<b>Float</b>		
G String	S7 String	G0.n-G65532.n STRING0.n- STRING65532.n .n is string length. 0 < n <= 210.	<b>String</b>		

See Also: [Examples](#)

### Suffixes

Suffix	Description	Data Type
BCD	Two byte packed BCD for Word references Value range is 0-9999  Four byte packed BCD for DWord references Value range is 0-99999999	BCD  LBCD
IEEE	32-bit IEEE floating point value	Float
KF	Signed	Char Short Long

### Array Support

The `<.array size>` notation is appended to an address to specify an array (such as MW0.10). Boolean arrays and string arrays are not supported.

### Examples

S7 Data Type	Data Type	Input	Flags	Data Blocks
X	Boolean	IX0.7	MX0.7	DB1.X0.7
B Byte	Byte	IB0 IBYTE0	MB0 MBYTE0	DB1.B0 DB1.BYTE0
	Char (KF)	IB0KF IBYTE0KF	MB0KF MBYTE0KF	DB1.B0KF DB1.BYTE0KF
	Array	IB0KF.10 IBYTE0KF.10	MB0KF.10 MBYTE0KF.10	DB1.B0KF.10 DB1.BYTE0KF.10
W Word	Word	IW0 IWORD0	MW0 MWORD0	DB1.W0 DB1.WORD0
	BCD (BCD)	IW0BCD IWORD0BCD	MW0BCD MWORD0BCD	DB1.W0BCD DB1.WORD0BCD
	Short (KF)	IW0KF IWORD0KF	MW0KF MWORD0KF	DB1.W0KF DB1.WORD0KF
	Array	IW0BCD.10 IWORD0BCD.10	MW0BCD.10 MWORD0BCD.10	DB1.W0BCD.10 DB1.WORD0BCD.10
I INT	Short	IIO IINT0	MIO MINT0	DB1.IO DB1.INT0
	BCD (BCD)	IIOBCD	MIOBCD	DB1.IOBCD

	Array	IINT0BCD IIO.10 IINT0.10	MINT0BCD MIO.10 MINT0.10	DB1.INT0BCD DB1.I0.10 DB1.INT0.10
D DWORD	DWord	ID0 IDWORD0	MD0 MDWORD0	DB1.D0 DB1.DWORD0
	LBCD (BCD)	ID0BCD IDWORD0BCD	MD0BCD MDWORD0BCD	DB1.D0BCD DB1.DWORD0BCD
	Float (IEEE)	ID0IEEE IDWORD0IEEE	MD0IEEE MDWORD0IEEE	DB1.D0IEEE DB1.DWORD0IEEE
	Long (KF)	ID0KF IDWORD0KF	MD0KF MDWORD0KF	DB1.D0KF DB1.DWORD0KF
	Array	ID0IEEE.10 IDWORD0IEEE.10	MD0IEEE.10 MDWORD0IEEE.10	DB1.D0IEEE.10 DB1.DWORD0IEEE.10
DI DINT	Long	IDIO IDINT0	MDIO MDINT0	DB1.DIO DB1.DINT0
	LBCD (BCD)	IDIOBCD IDINT0BCD	MDIOBCD MDINT0BCD	DB1.DIOBCD DB1.DINT0BCD
	Float (IEEE)	IDIOIEEE IDINT0IEEE	MDIOIEEE MDINT0IEEE	DB1.DIOIEEE DB1.DINT0IEEE
	Array	IDIOBCD.10 IDINT0BCD.10	MDIOBCD.10 MDINT0BCD.10	DB1.DIOBCD.10 DB1.DINT0BCD.10
R REAL	Float	IRO IREAL0	MRO MREAL0	DB1.R0 DB1.REAL0
	Array	IRO.10 IREAL0.10	MRO.10 MREAL0.10	DB1.R0.10 DB1.REAL0.10
G String	String	IG0.10 ISTRING0.10	MG0.10 MSTRING0.10	DB1.G0.10 DB1.STRING0.10

**Note:**

All brand and product names are trademarks, registered trademarks, or service marks of their respective holders.

**Siemens Simatic Net Item Syntax**

The following support for the Siemens Simatic Net OPC server is considered to be limited. Care must be taken as the data type for a given S7 data type may differ from the data type for the same S7 data type in the specified product. S7 data types not included below are not supported by this driver. The following information is intended to be a guideline for users that are already familiar with and/or prefer the syntax of the specified product. For preferred item syntax, refer to [Standard S7-300/400/1200/1500 Item Syntax](#).

**Address Syntax****Input, Output, Peripheral, Flag Memory Types**

<memory type><S7 data type> <address>  
 <memory type><S7 data type> <address> <.string length>  
 <memory type><S7 data type> <address> <,array size>

**Timer and Counter Memory Types**

<memory type> <address>

**DB Memory Type**

DB<num>, <S7 data type> <address>  
 DB<num>, <S7 data type> <address> <.string length> \*  
 DB<num>, <S7 data type> <address> <,array size>

Where <num> ranges from 1 to 65535.

\*Applies to S7 data types that support String.

See Also: [Examples](#)

### Memory Types

Memory Type	Description	Address Range	Data Type	Access
I E	Inputs	Dependent on S7 Data Type		Read/Write
Q A	Outputs			Read/Write
PI PE	Peripheral Inputs			Read Only
PQ PA	Peripheral Outputs			Read/Write
M F	Flag Memory			Read/Write
DB	Data Blocks			Read/Write
T	Timers	T0-T65535	DWord, <b>Long</b>	Read/Write
C Z	Counters	C0-C65535 Z0-Z65535	<b>Word</b> , Short	Read/Write

See Also: [Examples](#)

### S7 Data Types

The S7 data type is used to coerce the data type for a tag. It does not apply to Timers and Counters. The default data types are shown in **bold**.

Data Type	Description	Address Range	Data Type
X	Bit	X0.b-X65534.b .b is Bit Number 0-15	<b>Boolean</b>
B Byte	Unsigned Byte	B0-B65535 BYTE0-BYTE65535	<b>Byte</b> , Char
Char	Signed Byte	CHAR0-CHAR65535	Byte, <b>Char</b>
W Word	Unsigned Word	W0-W65534 WORD0-WORD65534	<b>Word</b> , Short, BCD
INT	Signed Word	INT0-INT65534	Word, <b>Short</b> , BCD
D DWORD	Unsigned Double Word	D0-D65532 DWORD0-DWORD65532	<b>DWord</b> , Long, LBCD, Float
DINT	Signed Double Word	DINT0-DINT65532	DWord, <b>Long</b> , LBCD, Float
REAL	IEEE Float	REAL0-REAL65532	<b>Float</b>
String	S7 String	STRING0.n-STRING65532.n .n is string length. 0 < n <= 210.	<b>String</b>

See Also: [Examples](#)

### Array Support

The `<.array size>` notation is appended to an address to specify an array (such as MW0.10). Boolean arrays and string arrays are not supported.

### Examples

S7 Data Type	Data Type	Input	Flags	Data Blocks
X	Boolean	IX0.7	MX0.7	DB1,X0.7
B Byte	Byte	IB0 IBYTE0	MB0 MBYTE0	DB1,B0 DB1,BYTE0
	Array	IB0,10 IBYTE0,10	MB0,10 MBYTE0,10	DB1,B0,10 DB1,BYTE0,10
Char	Char	ICHAR0	MCHAR0	DB1,CHAR0

	Array	ICHAR0,10	MCHAR0,10	DB1,CHAR0,10
W Word	Word	IW0 IWORD0	MW0 MWORD0	DB1,W0 DB1,WORD0
	Array	IW0,10 IWORD0,10	MW0,10 MWORD0,10	DB1,W0,10 DB1,WORD0,10
INT	Short	IINT0	MINT0	DB1,INT0
	Array	IINT0,10	MINT0,10	DB1,INT0,10
D DWORD	DWord	ID0 IDWORD0	MD0 MDWORD0	DB1,D0 DB1,DWORD0
	Array	ID0,10 IDWORD0,10	MD0,10 MDWORD0,10	DB1,D0,10 DB1,DWORD0,10
DINT	Long	IDINT0	MDINT0	DB1,DINT0
	Array	IDINT0,10	MDINT0,10	DB1,DINT0,10
REAL	Float	IREAL0	MREAL0	DB1,REAL0
	Array	IREAL0,10	MREAL0,10	DB1,REAL0,10
String	String	ISTRING0.10	MSTRING0.10	DB1,STRING0.10

**Note:**

All brand and product names are trademarks, registered trademarks, or service marks of their respective holders.

**Siemens STEP 7 Item Syntax**

The following support for Siemens STEP 7 Variable Table (VAT) syntax is considered to be limited. Care must be taken as the data type for a given S7 data type/suffix may differ from the data type for the same S7 data type/suffix in the specified product. S7 data types not included below are not supported by this driver. The following information is intended to be a guideline for users that are already familiar with and/or prefer the syntax of the specified product. For preferred item syntax, refer to [Standard S7-300/400/1200/1500 Item Syntax](#).

**Address Syntax****Input, Output, Peripheral, Flag Memory Types**

<memory type> <S7 data type> <address>

**Timer and Counter Memory Types**

<memory type> <address>

**DB Memory Type**

DB<num>.<S7 data type> <address>

Where <num> ranges from 1 to 65535.

See Also: [Examples](#)

**Memory Types**

Memory Type	Description	Address Range	Data Type	Access
I E	Inputs	Dependent on S7 Data Type		Read/Write
Q A	Outputs			Read/Write
PI PE	Peripheral Inputs			Read Only
PQ PA	Peripheral Outputs			Read/Write
M F	Flag Memory			Read/Write
DB	Data Blocks			Read/Write
T	Timers			T0-T65535

C	Counters	C0-C65535	<b>Word</b> , Short	Read/Write
Z		Z0-Z65535		

See Also: [Examples](#)

### Accessing Structured Elements in STEP 7

For the Siemens S7-1200 model, STEP 7 accesses the Counter and Timer structured elements as complete whole structures instead of individual tags. For more information on the element offset and its server address equivalent, refer to the tables below.

#### Counters

Element	Data Type	Offset	Server Address Equivalent
Count_UP	Boolean	0.0	DB1,C00.0
Count_Down	Boolean	0.1	DB1,C00.1
Reset	Boolean	0.2	DB1,C00.2
Load	Boolean	0.3	DB1,C00.3
Q_UP	Boolean	0.4	DB1,C00.4
Q_Down	Boolean	0.5	DB1,C00.5
PAD	Byte	1.0	DB1,B1
Preset_Value	Short	2.0	DB1,I2
Count_Value	Short	4.0	DB1,I4

#### Timers

Element	Data Type	Offset	Server Address Equivalent
Start	DWord	0.0	DB1,D0
Preset	DWord	4.0	DB1,D4
Elapsed	DWord	8.0	DB1,D8
Running	Bool	12.0	DB1,DBX12.0
IN	Bool	12.1	DB1,DBX12.1
Q	Bool	12.2	DB1,DBX12.2
PAD	Byte	13.0	DB1,DBB13
PAD_2	Byte	14.0	DB1,DBB14
PAD_3	Byte	15.0	DB1,DBB15

#### Note:

For more information, refer to [Standard S7-300/400/1200/1500 Item Syntax](#).

### S7 Data Types

The S7 data type is used to coerce the data type for a tag. It does not apply to Counters and Timers. The default data types are shown in **bold**.

Data Type	Description	Address Range	Data Type	Suffix	Data Type w/ Suffix
None* DBX**	Bit	0.b-65534.b DBX0.b- DBX65534.b .b is Bit Number 0- 15	<b>Boolean</b>		
B DBB**	Unsigned Byte	B0-B65535 DBB0-DBB65535	<b>Byte</b> , Char		
W DBW**	Unsigned Word	W0-W65534 DBW0-DBW65534	<b>Word</b> , Short, BCD		
D DBD**	Unsigned Double Word	D0-D65532 DBD0-DBD65532	<b>DWord</b> , Long, LBCD, Float	F	Float

\*No S7 data type specified. Applies to non-DB memory types only.

\*\*Applies to DB memory types only.

See Also: [Examples](#)

**Examples**

S7 Data Type	Data Type	Input	Flags	Data Blocks
None DBX	Boolean	I0.7 ----	M0.7 ----	---- DB1.DBX0.7
B DBB	Byte	IB0 ----	MB0 ----	---- DB1.DBB0
W DBW	Word	IW0 ----	MW0 ----	---- DB1.DBW0
D DBD	DWord	ID0 ----	MD0 ----	---- DB1.DBD0

**Note:**

All brand and product names are trademarks, registered trademarks, or service marks of their respective holders.

**Softing S7/S5 OPC Server Item Syntax**

The following support for the Softing S7/S5 OPC server is considered to be limited. Care must be taken as the data type for a given S7 data type/suffix may differ from the data type for the same S7 data type/suffix in the specified product. The following information is intended to be a guideline for users that are already familiar with and/or prefer the syntax of the specified product. For preferred item syntax, refer to [Standard S7-300/400/1200/1500 Item Syntax](#).

**Address Syntax****Input, Output, Peripheral, Flag Memory Types**

<memory type><S7 data type><address>:[<suffix>]

**Timer and Counter Memory Types**

<memory type><address>

**DB Memory Type**

DB<num>.<S7 data type><address>:[<suffix>]

Where <num> ranges from 1 to 65535.

See Also: [Examples](#)

**Memory Types**

Memory Type	Description	Address Range	Data Type	Access
I E	Inputs	Dependent on S7 Data Type		Read/Write
Q A	Outputs			Read/Write
PI PE	Peripheral Inputs			Read Only
PQ PA	Peripheral Outputs			Read/Write
M F	Flag Memory			Read/Write
DB	Data Blocks			Read/Write
T	Timers	T0-T65535	DWord, <b>Long</b>	Read/Write
C Z	Counters	C0-C65535 Z0-Z65535	<b>Word</b> , Short	Read/Write

See Also: [Examples](#)

**S7 Data Types**

The S7 data type is used to coerce the data type for a tag. It does not apply to Timers and Counters. The default data types are shown in **bold**. Suffix is not required.

Data Type	Description	Address Range	Data Type	Suffix	Data Type w/ Suffix
-----------	-------------	---------------	-----------	--------	------------------------



None* DBX**	Bit	0.b-65534.b DBX0.b- DBX65534.b .b is Bit Number 0- 15	<b>Boolean</b>		
B DBB**	Unsigned Byte	B0-B65535 DBB0-DBB65535	<b>Byte, Char</b>	Byte Char String	Byte Char String
W <b>DBW**</b>	Unsigned Word	W0-W65534 DBW0-DBW65534	<b>Word, Short, BCD</b>	Word INT BCD	Word INT BCD
D DBD**	Unsigned Double Word	D0-D65532 DBD0-DBD65532	<b>DWord, Long, LBCD, Float</b>	DWord DINT BCD REAL	DWord DINT BCD REAL

\*No S7 data type specified. Applies to non-DB memory types only.

\*\*Applies to DB memory types only.

See Also: [Examples](#)

### Suffixes

Suffix	Description	Data Type
Byte	Unsigned Byte	Byte
Char	Signed Byte	Char
Word	Unsigned Word	Word
INT	Signed Word	Short
DWORD	Unsigned DWord	DWord
DINT	Signed DWord	Long
BCD	Two byte packed BCD for Word references Value range is 0-9999	BCD
	Four byte packed BCD for DWord references Value range is 0-99999999	LBCD
REAL	32-bit IEEE floating point value	Float
String	S7 String	String

### Examples

S7 Data Type	Data Type	Input	Flags	Data Blocks
None DBX	Boolean	I0.7 ----	M0.7 ----	---- DB1.DBX0.7
B DBB	Byte	IB0 ----	MB0 ----	---- DB1.DBB0
	String (String)	IB0:String ----	MB0:String ----	---- DB1.DBB0:String
W DBW	Word	IW0 ----	MW0 ----	---- DB1.DBW0
	BCD (BCD)	IW0:BCD ----	MW0:BCD ----	---- DB1.DBW0:BCD
D DBD	DWord	ID0 ----	MD0 ----	---- DB1.DBD0
	LBCD (BCD)	ID0:BCD ----	MD0:BCD ----	---- DB1.DBD0:BCD
	Float (REAL)	ID0:REAL ----	MD0:REAL ----	---- DB1.DBD0:REAL

**Note:**

All brand and product names are trademarks, registered trademarks, or service marks of their respective holders.

### Legacy S7-300/400 Item Syntax

The default data types for dynamically defined tags are shown in **bold**. For preferred item syntax, refer to [Standard S7-300/400/1200/1500 Item Syntax](#).

Address Type	Range	Type	Access
Discrete Inputs	I0.b-I65535.b .b is Bit Number 0-7	<b>Boolean</b>	Read/Write
	IB0-IB65535 IW0-IW65534 IW:KT0-IW:KT65534 IW:KC0-IW:KC65534 ID0-ID65532	<b>Byte</b> , Char, String** <b>Word</b> , Short, BCD <b>DWord</b> , <b>Long</b> <b>Word</b> , Short <b>DWord</b> , Long, LBCD, Float	Read/Write Read/Write Read/Write Read/Write Read/Write
Discrete Inputs	E0.b-E65535.b .b is Bit Number 0-7	<b>Boolean</b>	Read/Write
	EB0-EB65535** EW0-EW65534 EW:KT0-EW:KT65534 EW:KC0-EW:KC65534 ED0-ED65532	<b>Byte</b> , Char, String** <b>Word</b> , Short, BCD <b>DWord</b> , <b>Long</b> <b>Word</b> , Short <b>DWord</b> , Long, LBCD, Float	Read/Write Read/Write Read/Write Read/Write Read/Write
<b>Note:</b> I and E access the same memory area.			
Discrete Outputs	Q0.b-Q65535.b .b is Bit Number 0-7	<b>Boolean</b>	Read/Write
	QB0-QB65535 QW0-QW65534 QW:KT0-QW:KT65534 QW:KC0-QW:KC65534 QD0-QD65532	<b>Byte</b> , Char, String** <b>Word</b> , Short, BCD <b>DWord</b> , <b>Long</b> <b>Word</b> , Short <b>DWord</b> , Long, LBCD, Float	Read/Write Read/Write Read/Write Read/Write Read/Write
Discrete Outputs	A0.b-A65535.b .b is Bit Number 0-7	<b>Boolean</b>	Read/Write
	AB0-AB65535 AW0-AW65534 AW:KT0-AW:KT65534 AW:KC0-AW:KC65534 AD0-AD65532	<b>Byte</b> , Char, String** <b>Word</b> , Short, BCD <b>DWord</b> , <b>Long</b> <b>Word</b> , Short <b>DWord</b> , Long, LBCD, Float	Read/Write Read/Write Read/Write Read/Write Read/Write
<b>Note:</b> Q and A access the same memory area.			
Peripheral Inputs	PI0.b-PI65535.b .b is Bit Number 0-7	<b>Boolean</b>	Read Only
	PIB0-PIB65535 PIW0-PIW65534 PIW:KT0-PIW:KT65534 PIW:KC0-PIW:KC65534 PID0-PID65532	<b>Byte</b> , Char, String** <b>Word</b> , Short, BCD <b>DWord</b> , <b>Long</b> <b>Word</b> , Short <b>DWord</b> , Long, LBCD, Float	Read Only Read Only Read Only Read Only Read Only
Peripheral Inputs	PE0.b-PE65535.b .b is Bit Number 0-7	<b>Boolean</b>	Read Only
	PEB0-PEB65535** PEW0-PEW65534 PEW:KT0-PEW:KT65534 PEW:KC0-PEW:KC65534 PED0-PED65532	<b>Byte</b> , Char, String** <b>Word</b> , Short, BCD <b>DWord</b> , <b>Long</b> <b>Word</b> , Short <b>DWord</b> , Long, LBCD, Float	Read Only Read Only Read Only Read Only Read Only

		Float	
<b>Note:</b> PI and PE access the same memory area.			
Peripheral Outputs	PQ0.b-PQ65535.b .b is Bit Number 0-7  PQB0-PQB65535 PQW0-PQW65534 PQW:KT0-PQW:KT65534 PQW:KC0-PQW:KC65534 PQD0-PQD65532	<b>Boolean</b>  <b>Byte</b> , Char, String** <b>Word</b> , Short, BCD DWord, <b>Long</b> <b>Word</b> , Short <b>DWord</b> , Long, LBCD, Float	Read/Write  Read/Write Read/Write Read/Write Read/Write
Peripheral Outputs	PA0.b-PA65535.b .b is Bit Number 0-7  PAB0-PAB65535 PAW0-PAW65534 PAW:KT0-PAW:KT65534 PAW:KC0-PAW:KC65534 PAD0-PAD65532	<b>Boolean</b>  <b>Byte</b> , Char, String** <b>Word</b> , Short, BCD DWord, <b>Long</b> <b>Word</b> , Short <b>DWord</b> , Long, LBCD, Float	Read/Write  Read/Write Read/Write Read/Write Read/Write
<b>Note:</b> PQ and PA access the same memory area.			
Internal Memory	F0.b-F65535.b .b is Bit Number 0-7  FB0-FB65535 FW0-FW65534 FW:KT0-FW:KT65534 FW:KC0-FW:KC65534 FD0-FD65532	<b>Boolean</b>  <b>Byte</b> , Char, String** <b>Word</b> , Short, BCD DWord, <b>Long</b> <b>Word</b> , Short <b>DWord</b> , Long, LBCD, Float	Read/Write  Read/Write Read/Write Read/Write Read/Write
Internal Memory	M0.b-M65535.b .b is Bit Number 0-7  MB0-MB65535 MW0-MW65534 MW:KT0-MW:KT65534 MW:KC0-MW:KC65534 MD0-MD65532	<b>Boolean</b>  <b>Byte</b> , Char, String** <b>Word</b> , Short, BCD DWord, <b>Long</b> <b>Word</b> , Short <b>DWord</b> , Long, LBCD, Float	Read/Write  Read/Write Read/Write Read/Write Read/Write
<b>Note:</b> F and M access the same memory area.			
Data Block Boolean	DB1-N:KM0.b-KM65534.b 1-N is Block Number .b is Bit Number 0-15  <b>Alternates</b>  DB1DBX0.b-DBNDBX65534.b 1-N is Block Number .b is Bit Number 0-15  DB1D0.b-DBND65534.b 1-N is Block Number .b is Bit Number 0-15	<b>Boolean</b>   <b>Boolean</b>  <b>Boolean</b>	Read/Write   Read/Write  Read/Write
Data Block Left Byte	DB1-N:KL0-KL65535 1-N is Block Number  <b>Alternates</b>  DB1DBB0-DBNDBB65535 1-N is Block Number  DB1DL0-DBNDL65535 1-N is Block Number	<b>Byte</b> , Char, String**   <b>Byte</b> , Char, String**  <b>Byte</b> , Char, String**	Read/Write   Read/Write  Read/Write

Data Block Right Byte	DB1-N:KR0-KR65534 1-N is Block Number  <b>Alternates</b>  DB1DR0-DBNDR65534 1-N is Block Number	<b>Byte</b> , Char, String**  <b>Byte</b> , Char, String**	Read/Write  Read/Write
Data Block Unsigned Word	DB1-N:KH0-KH65534 1-N is Block Number	<b>Word</b> , Short, BCD	Read/Write
Data Block Signed Word	DB1-N:KF0-KF65534 1-N is Block Number  <b>Alternates</b>  DB1DBW0-DBNDBW65534 1-N is Block Number  DB1DW0-DBNDW65534 1-N is Block Number	Word, <b>Short</b> , BCD  Word, <b>Short</b> , BCD  Word, <b>Short</b> , BCD	Read/Write  Read/Write  Read/Write
Data Block Signed Long	DB1-N:KD0-KD65532 1-N is Block Number  <b>Alternates</b>  DB1DBD0-DB1DBD65532 1-N is Block Number  DB1DD0-DB1DD65532 1-N is Block Number	DWord, <b>Long</b> , LBCD, Float  DWord, <b>Long</b> , LBCD, Float  DWord, <b>Long</b> , LBCD, Float	Read/Write  Read/Write  Read/Write
Data Block Float	DB1-N:KG0-KG65532 1-N is Block Number	<b>Float</b>	Read/Write
Data Block BCD	DB1-N:BCD0-BCD65534 1-N is Block Number	<b>Word</b> , Short, BCD	Read/Write
Data Block S5 Timer as DB	DB1-N:KT0-KT65534 1-N is Block Number	DWord, <b>Long</b>	Read/Write
Data Block S5 Counter as DB	DB1-N:KC0-KC65534 1-N is Block Number	<b>Word</b> , Short	Read/Write
Data Block String***	DB1S0.n-DB1S65535.n* .n is string length. 0 < n <= 212.	<b>String</b>	Read/Write
Data Block String***	DB1STRING0.n- DB1STRING65535.n* .n is string length. 0 < n <= 210.	String	Read/Write
Timer Current Values****	T0-T65535*	DWord, <b>Long</b>	Read/Write
Counter Current Values*****	C0-C65535*	<b>Word</b> , Short	Read/Write
Counter Current Values*****	Z0-Z65535*	<b>Word</b> , Short	Read/Write

\*These memory types/subtypes do not support arrays.

\*\*Byte memory types (like MB) support Strings. The syntax for strings is <address>.<length> where 0 < length <= 212.

\*\*\*For more information, refer to [Data Block Strings](#).

\*\*\*\*For more information, refer to [Timers](#).

\*\*\*\*\*For more information, refer to [Counters](#).

#### Notes:

1. All offsets for memory types I, Q, and F represent a byte starting location within the specified memory type.

- Use caution when modifying Word, Short, DWord, and Long types. For I, Q, and F each address starts at a byte offset within the device. Therefore, Words FW0 and FW1 overlap at byte 1. Writing to FW0 will also modify the value held in FW1. Similarly, DWord, and Long types can also overlap. It is recommended that these memory types be used so that overlapping does not occur. For example, DWord, FD0, FD4, FD8 and so on can be used to prevent overlapping bytes.

### Data Block Strings

Data block Strings can be referenced by using S subtypes or String subtypes.

#### S Subtype

The syntax for the S subtype is *DBxSy.n* where *x* is the data block, *y* is the byte offset, and *n* is the maximum String length. String values read and written are stored at byte offset *y* in data block *x*.

y	y+1	y+2	...	y+n-1
''	''	''	...	''

S Strings are null terminated. If the maximum string length is 10 and 3 characters are written, the fourth character is set to NULL, while characters 5-10 are left untouched.

#### String Subtype

The String subtype follows the STEP 7 String data type definition. The syntax for the String subtype is *DBxSTRINGy.n*, where *x* is the data block, *y* is the Byte offset, and *n* is the maximum String length. If *n* is not specified, the maximum String length will be 210 characters. String values read and written are stored at Byte offset *y+2* in data block *x*. The first two bytes contain the maximum string length (*n*) and the actual string length. The actual string length gets updated with every write based on the string length of the string being written.

y	y+1	y+2	y+3	y+4	...	y+2+n-1
maximum string length (n)	actual string length	''	''	''	...	''

#### Note:

String Strings are NULL padded. If the maximum string length is 10 and 3 characters are written, characters 4-10 are set to NULL.

### Hex Strings

The HEXSTRING subtype is specific to the Siemens TCP/IP Ethernet Driver. The syntax for the HEXSTRING subtype is *HEXSTRINGy.n*, where *y* is the byte offset and *n* is the length. The *n* value must be specified in the range of 1 through 212. String is the only valid data type for a HEXSTRING tag.

The value assigned to a HEXSTRING must be an even number of characters. There is no padding, so the entire string must be specified. For example, tag HexStr defined as DB1,STRING0.10 uses 10 bytes of storage and has a display length of 20. To assign a value, the string must be 20 characters long and contain only valid hexadecimal characters. An example valid hex string for this tag is "56657273696f6E353137".

### Arrays

All memory types/subtypes with the exception of those marked with an asterisk support arrays. The syntax below are valid for declaring an array. If no rows are specified, a row count of 1 is assumed.

```
<address>[rows][cols]
<address>.rows.cols
<address>,rows,cols
<address>_rows_cols
```

For Word, Short, BCD and "KT" arrays, the base address + (rows \* cols \* 2) cannot exceed 65536. Keep in mind that the elements of the array are words, located on a word boundary. For example, IW0[4] would return IW0, IW2, IW4, and IW6. "KT" subtypes fall into the 16-bit category because the data stored in the PLC is contained within a Word. For more information, refer to [Timers](#).

For Float, DWord, Long, and Long BCD arrays (excluding "KT" subtypes), the base address + (rows \* cols \* 4) cannot exceed 65536. Keep in mind that the elements of the array are DWord, located on a DWord boundary. For example, ID0[4] will return ID0, ID4, ID8, ID12.

For all arrays, the total number of bytes being requested cannot exceed the internal block size of 212 bytes.

**KL vs. KR vs. DBB**

KL and KR determine whether the left byte or right byte of the data block word is returned.

<b>Value</b>	8	9	A	B	C
<b>Byte</b>	0	1	2	3	4

The following examples are from the table above.

**Example 1**

DB1:KH0=0x89.  
 DB1:KL0=0x8  
 DB1:KR0=0x9  
 DB1:DBB0=0x8

**Example 2**

DB1:KH1=0x9A  
 DB1:KL1=0x9  
 DB1:KR1=0xA  
 DB1:DBB1=0x9

**Timers**

The Siemens TCP/IP Ethernet Driver automatically scales T and KT values based on the Siemens S5 time format. Timer data is stored as a Word in the PLC but scaled to a DWord in the driver. The value returned for either a T or KT memory type will already be scaled using the appropriate Siemens time base. As a result, the values are always returned as a count of milliseconds. When writing to T or KT memory types, the Siemens time base will also be applied. To assign a value to a timer in the controller, write the desired value as a count of milliseconds to the appropriate timer.

**Counters**

The value returned for either C or KC memory type will automatically be converted to a BCD value. DB1:KH0 @ BCD=DB1:KC0 @ Word.

**Examples**

1. To access bit 3 of internal memory F20, declare an address as follows: F20.3
2. To access data block 5 as word memory at byte 30, declare an address as follows: DB5:KH30
3. To access data block 2 byte 20 and bit 7, declare an address as follows: DB2:KM20.7
4. To access data block 1 as left byte memory at byte 10, declare an address as follows: DB1:KL10
5. To access internal memory F20 as a DWORD, declare an address as follows: FD20
6. To access Input memory I10 as a Word, declare an address as follows: IW10

## Error Descriptions

The following classes of error/warning messages may be generated. Click on the link for a list messages in each category.

[Address Validation Error Messages](#)

[Automatic Tag Generation Error Messages](#)

[Driver Error Messages](#)

[Device Status Error Messages](#)

## Error Codes

### NetLink Errors

Error Code	Source	Description
0x00		Service could be executed without an error
0x01	Remote Station	Timeout from remote station
0x02	Remote Station	Resource unavailable
0x03	Remote Station	Requested function of master is not activated within the remote station
0x11	Remote Station	No response of the remote station
0x12	Network	Master not into the logical token ring
0x14	Host	Resource of the local FDL controller not available or not sufficient
0x15	Host	The specified msg.data_cnt parameter is invalid
0x30	Remote Station	Timeout. The requested message was accepted but no indication was sent back by the remote station
0x39	Remote Station	Sequence fault, internal state machine error
0x85	Host	Specified offset address out of limits or unknown in the remote station
0x86	Device	Wrong PDU coding in the MPI response of the remote station
0x87	Host	Specified length to write or to read results in an access outside of limits

### Transport Errors

Error Code	Description
0x00	Error reason not specified
0x01	Invalid parameter code
0x02	Invalid TPDU type
0x03	Invalid parameter value

### Protocol Errors

#### Note:

Links contain the error codes for the given class.

Error Class	Description
0x00	No error
0x81	Error in the application ID of the request
0x82	Error in the object definition (e.g. bad data type)
0x83	No resources available
0x84	Error in the structure of the service request
0x85	Error in the communication equipment
0x87	Access error
0xD2	OVS error
0xD4	Diagnostic error
0xD6	Protection system error
0xD8	BuB error
0xEF	Layer 2 specific error

**Data Access Errors**

Error Code	Description
0xFF	No error
0x01	Hardware fault
0x03	Illegal object access
0x05	Invalid address (incorrect variable address)
0x06	Data type is not supported
0x07	Invalid data size/too much data
0x0A	Object does not exist or length error

**Address Validation Error Messages**

The following error/warning messages may be generated. Click on the link for a description of the message.

[Address <address> is out of range for the specified device or register.](#)

[Array size is out of range for address <address>.](#)

[Array support is not available for the specified address: <address>.](#)

[Data type <type> is not valid for device address <address>.](#)

[Device address <address> contains a syntax error.](#)

[Device address <address> is read only.](#)

[Missing address.](#)

**Address <address> is out of range for the specified device or register.****Error Type:**

Warning

**Possible Cause:**

A tag address that has been specified dynamically references a location that is beyond the range of supported locations for the device.

**Solution:**

Verify the address is correct; if it is not, re-enter it in the client application.

**Array size is out of range for address <address>.****Error Type:**

Warning

**Possible Cause:**

A tag address that has been specified dynamically is requesting an array size that is too large for the address type or block size of the driver.

**Solution:**

Re-enter the address in the client application to specify a smaller value for the array or a different starting point.

**Array Support is not available for the specified address: <address>.****Error Type:**

Warning

**Possible Cause:**

A tag address that has been specified dynamically contains an array reference for an address type that doesn't support arrays.

**Solution:**

Re-enter the address in the client application to remove the array reference or correct the address type.



---

**Data type <type> is not valid for device address <address>.**

---

**Error Type:**

Warning

**Possible Cause:**

A tag address that has been specified dynamically has been assigned an invalid data type.

**Solution:**

Modify the requested data type in the client application.

---

**Device address <address> contains a syntax error.**

---

**Error Type:**

Warning

**Possible Cause:**

A tag address that has been specified dynamically contains one or more invalid characters.

**Solution:**

Re-enter the address in the client application.

---

**Device address <address> is read only.**

---

**Error Type:**

Warning

**Possible Cause:**

A tag address that has been specified dynamically has a requested access mode that is not compatible with what the device supports for that address.

**Solution:**

Change the access mode in the client application.

---

**Missing address.**

---

**Error Type:**

Warning

**Possible Cause:**

A tag address that has been specified dynamically has no length.

**Solution:**

Re-enter the address in the client application.

---

**Automatic Tag Generation Error Messages**

---

The following error/warning messages may be generated. Click on the link for a description of the message.

[Language file warning for device <channel.device>: Memory exception reading the STEP 7 language file.](#)[Language file warning for device <channel.device>: STEP 7 language file failed to open \[Reason\].](#)[Language file warning for device <channel.device>: Unable to load STEP 7 language file.](#)[String conversion warning: Auto generated tag names and descriptions may not appear as expected for device <channel.device>.](#)[Unable to generate a tag database for device <channel.device>. Reason: The program path has not been specified.](#)[Unable to generate a tag database for device <channel.device>. Reason: The STEP 7 project file has not been specified.](#)[Unable to generate a tag database for device <device name>. Reason: <model> devices do not support auto tag database generation.](#)

Unable to generate a tag database for device <device name>. Reason: Failed to read data from the STEP 7 project.

Unable to generate a tag database for device <device name>. Reason: File system error processing the STEP 7 project.

Unable to generate a tag database for device <device name>. Reason: Internal driver error occurred.

Unable to generate a tag database for device <device name>. Reason: The specified CPU is not supported.

Unable to generate a tag database for device <device name>. Reason: Unable to open STEP 7 project.

Unable to generate tag(s) on device <device> for <data block name> data block <data block number>.

Unable to generate tag(s) on device <device> for <tag group>. Array tag not supported for data type <data type>. Tag <tag name> not created.

Unable to generate tag(s) on device <device> for <tag group>. Created tag <tag name> with address <tag address> due to internal block size.

Windows code page warning for device <channel.device>: A required code page (<nnnn>) is unavailable on this machine. Tag generation may fail or tag names and descriptions may not appear as expected.

### **Language file warning for device <channel.device>: Memory exception reading the STEP 7 language file.**

---

**Error Type:**

Warning

**Possible Cause:**

The operating system has insufficient memory to read the STEP 7 language file.

**Solution:**

Ensure that the system resources are adequate for all applications running on the computer.

### **Language file warning for device <channel.device>: STEP 7 language file failed to open [Reason].**

---

**Error Type:**

Warning

**Possible Cause:**

The STEP 7 language file is altered or corrupt.

**Solution:**

1. Investigate the reason that has been provided.
2. Verify that the Simatic STEP 7 project is not corrupt and can be successfully opened in Simatic STEP 7. If this error continues to occur, contact Technical Support.

### **Language file warning for device <channel.device>: Unable to load STEP 7 language file.**

---

**Error Type:**

Warning

**Possible Cause:**

1. The STEP 7 language file is altered or corrupt.
2. The Windows code page is not available on the computer.

**Solution:**

Verify that the Simatic STEP 7 project is not corrupt and can be successfully opened in Simatic STEP 7. If this error continues to occur, contact Technical Support.

**String conversion warning: Auto generated tag names and descriptions may not appear as expected for device <channel.device>.**

---

**Error Type:**

Warning

**Possible Cause:**

The unicode conversion failed.

**Solution:**

Verify that the STEP 7 language file exists and reflects a character set that can display the STEP 7 tags and comment strings.

**Unable to generate a tag database for device <channel.device>. Reason: The STEP 7 project file has not been specified.**

---

**Error Type:**

Warning

**Possible Cause:**

The STEP 7 project file has not been specified.

**Solution:**

Verify that the STEP 7 project file has been specified in the Tag Import tab of Device Properties.

**See Also:**

[Tag Import](#)

**Unable to generate a tag database for device <channel.device>. Reason: The program path has not been specified.**

---

**Error Type:**

Warning

**Possible Cause:**

The STEP 7 program path has not been specified.

**Solution:**

Verify that the STEP 7 program path has been specified in the Tag Import tab of Device Properties.

**See Also:**

[Tag Import](#)

**Unable to generate a tag database for device <device name>. Reason: <model> devices do not support auto tag database generation.**

---

**Error Type:**

Warning

**Possible Cause:**

The selected model does not currently support Automatic Tag Database Generation.

**Solution:**

Generate the tags manually.

**Note:**

Automatic Tag Database Generation is only supported for the S7-300 and S7-400 device models.

**Unable to generate a tag database for device <device name>. Reason: Failed to read data from the STEP 7 project.**

---

**Error Type:**

Warning

**Possible Cause:**

One of the files in the STEP 7 project folder is missing, invalid, or corrupt.

**Solution:**

Verify that the entire STEP 7 project folder is available at the location specified in the S7 project file parameter (located in the Tag Import tab of Device Properties).

**See Also:**

[Tag Import](#)

**Unable to generate a tag database for device <device name>. Reason: File system error processing the STEP 7 project.**

---

**Error Type:**

Warning

**Possible Cause:**

1. The STEP 7 project is in use and is locked.
2. The STEP 7 project is not accessible.
3. The disk is full or write-protected.

**Solution:**

1. Ensure that the STEP 7 project is not in use.
2. Ensure that the STEP 7 project's file location is accessible and that its user permissions allow access.
3. Ensure that the disk is not full or write-protected.

**Note:**

The folder that contains the STEP 7 project file must be complete with all sub-folders and files.

**See Also:**

[Tag Import](#)

**Unable to generate a tag database for device <device name>. Reason: Internal driver error occurred.**

---

**Error Type:**

Warning

**Possible Cause:**

Tag generation was unable to start due to an unknown error.

**Solution:**

Retry the tag generation.

**Unable to generate a tag database for device <device name>. Reason: The specified CPU is not supported.**

---

**Error Type:**

Warning

**Possible Cause:**

Automatic Tag Database Generation is not supported for the CPU object configured in the STEP 7 project. At this time, only S7-300 and S7-400 CPU types are supported.

**Solution:**

Verify that the station, CPU, and program specified in the Program Path field (located in the Tag Import tab of Device Properties) match those in the STEP 7 project. If the properties match, then Automatic Tag Database Generation is not supported and the tags must be manually created. If modifications have been made to the Program Path property's information, retry Automatic Tag Database Generation.

**Unable to generate a tag database for device <device name>. Reason: Unable to open STEP 7 project.**

---

**Error Type:**

Warning

**Possible Cause:**

The path specified for the S7 project file (located in the Tag Import tab of Device Properties) does not exist.

**Solution:**

Select a valid STEP 7 project file.

**Note:**

The folder containing the STEP 7 project file must be complete with all sub-folders and files.

**See Also:**

[Tag Import](#)

**Unable to generate tag(s) on device <device> for <data block name> data block <data block number>.**

---

**Error Type:**

Warning

**Result:**

Automatic tag generation did not complete for the specified data block.

**Possible Cause:**

An unexpected data type or other issue occurred during the parsing of the STEP 7 project for the specified data block.

**Solution:**

Compare the tags that did automatically generate with those in the STEP 7 project for the specified data block to determine which tag caused the incomplete data block tag generation. Then, report any issues to Technical Support.

**Unable to generate tag(s) on device <device> for <tag group>. Array tag not supported for data type <data type>. Tag <tag name> not created.**

---

**Error Type:**

Warning

**Possible Cause:**

While parsing the data blocks of the STEP 7 project for automatic tag generation, an array variable was encountered with a data type for which the driver does not support arrays.

**Solution:**

The client must access the data using the array element tags that were generated.

**Notes:**

1. Variables with the STEP 7 data types of DATE, DATE\_AND\_TIME, STRING, TIME, and TIME\_OF\_DAY generate tags with the string data type (for which arrays are not supported).
2. During automatic tag generation for arrays of complex types (such as structures, user-defined types, function blocks, or system function blocks), this warning message only occurs for tags of the first element of the complex type array.

---

**Unable to generate tag(s) on device <device> for <tag group>. Created tag <tag name> with address <tag address> due to internal block size.**

---

**Error Type:**

Warning

**Possible Cause:**

While parsing the data blocks of the STEP 7 project for automatic tag generation, an array variable was encountered that exceeds the internal block size. Although all individual array element tags generate as expected, the array tag itself is generated with a dimension that allows it to fit within the block size.

**Solution:**

To use array tags and not the individual array element tags, determine the address where the array tag leaves off. Then, manually generate another tag to address the remainder of the array.

**Notes:**

1. For example, if data block 1 begins with an array of 64 REAL, there would be 64 array element tags with addresses DB1,REAL0; DB1,REAL4;... DB1, REAL248; DB1,REAL252. Because the size of the array exceeds the internal block size of 218, the array tag would only be created with 54 dimensions ("DB1,REAL0[54]"). The array tag does not provide the client with the data for the last 10 elements. If the client wants to use array tags and not the individual array element tags, another tag with the address "DB1,REAL216[10]" must be manually created.
2. During automatic tag generation for arrays of complex types (such as structures, user-defined types, function blocks, or system function blocks), this warning message only occurs for tags of the first element of the complex type array.

---

**Windows code page warning for device <channel.device>: A required code page (<nnnn>) is unavailable on this machine. Tag generation may fail or tag names and descriptions may not appear as expected.**

---

**Error Type:**

Warning

**Possible Cause:**

The computer is not configured with support for the specified Windows code page.

**Solution:**

1. Install any language packs that are necessary for displaying the Windows code page character set.
2. Move to a computer that supports the Windows code page.

---

**Driver Error Messages**

---

The following error/warning messages may be generated. Click on the link for a description of the message.

[Winsock initialization failed \(OS error= n\).](#)

[Winsock V1.1 or higher must be installed to use the Siemens TCP/IP Ethernet device driver.](#)

**Winsock initialization failed (OS error=n).****Error Type:**

Fatal

OS Error	Indication	Possible Solution
10091	Indicates that the underlying network subsystem is not ready for network communication.	Wait a few seconds and restart the driver.
10067	Limit on the number of tasks supported by the Windows Sockets implementation has been reached.	Close one or more applications that may be using Winsock and restart the driver.

**Winsock V1.1 or higher must be installed to use the Siemens TCP/IP Ethernet device driver.****Error Type:**

Fatal

**Possible Cause:**

The version number of the Winsock DLL found on the system is less than 1.1.

**Solution:**

Upgrade Winsock to version 1.1 or higher.

**Device Status Error Messages**

The following error/warning messages may be generated. Click on the link for a description of the message.

[Device <device name> is not responding.](#)

[Unable to connect to device <device name>. Device returned transport error \[Code=<code>\].](#)

[Unable to connect to device <device name>. Frame contains errors.](#)

[Unable to establish association with device <device name>. Device returned protocol error \[Class=<class>, Code=<code>\].](#)

[Unable to establish association with device <device name>. Device returned transport error \[Code=<code>\].](#)

[Unable to establish association with device <device name>. Frame contains errors.](#)

[Unable to read <block size> bytes starting at address <address> on device <device name>. Device returned data access error \[Code=<code>\].](#)

[Unable to read <block size> bytes starting at address <address> on device <device name>. Device returned protocol error \[Class=<class>, Code=<code>\].](#)

[Unable to read <block size> bytes starting at address <address> on device <device name>. Device returned transport error \[Code=<code>\].](#)

[Unable to read <block size> bytes starting at address <address> on device <device name>. Frame contains errors.](#)

[Unable to read <block size> bytes starting at address <address> on device <device name>. NetLink returned error \[Code=<code>\].](#)

[Unable to write to <address> on device <device name>. Device not responding.](#)

[Unable to write to <address> on device <device name>. Device returned data access error \[Code=<code>\].](#)

[Unable to write to <address> on device <device name>. Device returned protocol error \[Class=<class>, Code=<code>\].](#)

[Unable to write to <address> on device <device name>. Device returned transport error \[Code=<code>\].](#)

[Unable to write to <address> on device <device name>. Frame contains errors.](#)

[Unable to write to <address> on device <device name>. NetLink returned error \[Code=<code>\].](#)

[Unable to write to <address> on device <device name>. Time of Day string <write string> contains a syntax error. Expected hh:mm:ss.hhh format.](#)

[Unable to write to address <address> on device <device>. Date string <write string> contains a syntax error. Expected yyyy-mm-dd format.](#)

[Unable to write to address <address> on device <device>. Time string <write string> contains a syntax error. Expected ddD\\_hhH\\_mmM\\_ssS\\_hhhMS format.](#)

**Device <device name> is not responding.**

---

**Error Type:**

Warning

**Result:**

If tag was being read:

- If tag is a block tag, the entire block will be invalidated. All tags within that block will be invalidated.
- If tag is an array tag or string tag, just this tag will be invalidated.

If tag was being written:

- Write operation for the given tag will not take place.

**Possible Cause:**

1. The connection between the device and the host PC is broken.
2. The response from the device took longer to receive than the amount of time specified in the "Request Timeout" device setting.
3. The named device may have been assigned an incorrect IP address.
4. The device's CPU work load is too high.

**Solution:**

1. Verify the cabling between the PC and the PLC's device.
2. Increase the Request Timeout setting so that the entire response can be handled.
3. Verify the IP address given to the named device matches that of the actual device.
4. If this error occurs frequently, decrease the tag group scan rate to reduce the work load on the PLC's CPU.
5. Increase the Scan Cycle Load from Communication and Scan Cycle Monitoring Time.

**Unable to connect to device <device name>. Device returned transport error [Code=<code>].**

---

**Error Type:**

Warning

**Result:**

1. If tag is to be read in the process of connecting, and a device error (transport) occurred:

- If tag is a block tag, the entire block will be deactivated. All tags within that block will be deactivated. This is signified by the postfix message "...Block Deactivated."
- If tag is an array tag or string tag, just this tag will be deactivated. This is signified by the postfix message "...Tag Deactivated."

2. If tag is to be read in the process of connecting, and no device errors occurred:

- If tag is a block tag, the entire block will be invalidated. All tags within that block will be invalidated.
- If tag is an array tag or string tag, just this tag will be invalidated.

3. If tag is to be written in the process of connecting:

- Write operation for the given tag will not take place.

**Possible Cause:**

An RFC1006 error (ISO over TCP/IP) occurred. This is the portion of the packet that encapsulates the S7 Messaging packet.

**Solution:**

Contact Technical Support.



**Note:**

No protocol or data access errors can occur for this operation.

**See Also:**

[Error Codes](#)

**Unable to connect to device <device name>. Frame contains errors.**

---

**Error Type:**

Warning

**Result:**

1. If tag is to be read in the process of connecting, and a device error (transport) occurred:
  - If tag is a block tag, the entire block will be deactivated. All tags within that block will be deactivated. This is signified by the postfix message "...Block Deactivated."
  - If tag is an array tag or string tag, just this tag will be deactivated. This is signified by the postfix message "...Tag Deactivated."
2. If tag is to be read in the process of connecting, and no device errors occurred:
  - If tag is a block tag, the entire block will be invalidated. All tags within that block will be invalidated.
  - If tag is an array tag or string tag, just this tag will be invalidated.
3. If tag is to be written in the process of connecting:
  - Write operation for the given tag will not take place.

**Possible Cause:**

1. The TPDU response size is incorrect.
2. An unexpected frame was received. The response code may be incorrect.
3. The frame sequence is out of order.
4. The device's CPU work load is too high.

**Solution:**

1. Cable noise may cause distortion in the frame, resulting in erroneous data. It may also cause dropped frames. Verify the cabling between the PC and the PLC's device.
2. Reduce network traffic. If this error occurs frequently, increase the Request Timeout and/or Fail After attempt count.
3. If this error occurs frequently, decrease the tag group scan rate to reduce the work load on the PLC's CPU.
4. Increase the "Scan Cycle Load from Communication" and "Scan Cycle Monitoring Time".

**See Also:**

[Error Codes](#)

**Unable to establish association with device <device name>. Device returned protocol error [Class=<class>, Code=<code>].**

---

**Error Type:**

Warning

**Result:**

1. If tag is to be read in the process of establishing an association, and a device error (such as transport or protocol) occurred:
  - If tag is a block tag, the entire block will be deactivated. All tags within that block will be deactivated. This is signified by the postfix message "...Block Deactivated."

- If tag is an array tag or string tag, just this tag will be deactivated. This is signified by the postfix message "...Tag Deactivated."
2. If tag is to be read in the process of establishing an association, and no device errors occurred:
    - If tag is a block tag, the entire block will be invalidated. All tags within that block will be invalidated.
    - If tag is an array tag or string tag, just this tag will be invalidated.
  3. If tag is to be written in the process of connecting:
    - Write operation for the given tag will not take place.

**Possible Cause:**

An S7 Messaging error occurred. This will occur if this portion is malformed or contains incorrect packet lengths.

**Solution:**

Contact Technical Support.

**Note:**

No data access errors can occur for this operation.

**See Also:**

[Error Codes](#)

---

**Unable to establish association with device <device name>. Device returned transport error [Code=<code>].**

---

**Error Type:**

Warning

**Result:**

1. If tag is to be read in the process of establishing an association, and a device error (such as transport or protocol) occurred:
  - If tag is a block tag, the entire block will be deactivated. All tags within that block will be deactivated. This is signified by the postfix message "...Block Deactivated."
  - If tag is an array tag or string tag, just this tag will be deactivated. This is signified by the postfix message "...Tag Deactivated."
2. If tag is to be read in the process of establishing an association, and no device errors occurred:
  - If tag is a block tag, the entire block will be invalidated. All tags within that block will be invalidated.
  - If tag is an array tag or string tag, just this tag will be invalidated.
3. If tag is to be written in the process of connecting:
  - Write operation for the given tag will not take place.

**Possible Cause:**

An RFC1006 error (ISO over TCP/IP) occurred. This is the portion of the packet that encapsulates the S7 Messaging packet.

**Solution:**

Contact Technical Support.

**See Also:**

[Error Codes](#)

---

**Unable to establish association with device <device name>. Frame contains errors.**

---

**Error Type:**

Warning

**Result:**

1. If tag is to be read in the process of establishing an association, and a device error (such as transport or protocol) occurred:
  - If tag is a block tag, the entire block will be deactivated. All tags within that block will be deactivated. This is signified by the postfix message "...Block Deactivated."
  - If tag is an array tag or string tag, just this tag will be deactivated. This is signified by the postfix message "...Tag Deactivated."
2. If tag is to be read in the process of establishing an association, and no device errors occurred:
  - If tag is a block tag, the entire block will be invalidated. All tags within that block will be invalidated.
  - If tag is an array tag or string tag, just this tag will be invalidated.
3. If tag is to be written in the process of connecting:
  - Write operation for the given tag will not take place.

**Possible Cause:**

1. The TPDU response size is incorrect.
2. An unexpected frame was received. The response code may be incorrect.
3. The frame sequence is out of order.
4. The device's CPU work load is too high.

**Solution:**

1. Cable noise may cause distortion in the frame, resulting in erroneous data. It may also cause dropped frames. Verify the cabling between the PC and the PLC's device.
2. Reduce network traffic. If this error occurs frequently, increase the Request Timeout and/or Fail After attempt count.
3. If this error occurs frequently, decrease the tag group scan rate to reduce the work load on the PLC's CPU.
4. Increase the "Scan Cycle Load from Communication" and "Scan Cycle Monitoring Time".

**See Also:**

[Error Codes](#)

**Unable to read <block size> bytes starting at address <address> on device <device name>. Device returned data access error [Code=<code>].****Error Type:**

Warning

**Result:**

1. If device error (such as transport, protocol, or access) occurred:
  - If tag is a block tag, the entire block (address -> address + block size) will be deactivated. All tags within that block will be deactivated. This is signified by the postfix message "...Block Deactivated."
  - If tag is an array tag or string tag, just this tag will be deactivated. This is signified by the postfix message "...Tag Deactivated."
2. If no device errors occurred:
  - If tag is a block tag, the entire block will be invalidated. All tags within that block will be invalidated.
  - If tag is an array tag or string tag, just this tag will be invalidated.

**Possible Cause:**

A data access error occurred. This will occur if, for instance, a requested address is out of range or is being referenced incorrectly.

**Solution:**

Contact Technical Support.

**See Also:**

[Error Codes](#)

**Unable to read <block size> bytes starting at address <address> on device <device name>. Device returned protocol error [Class=<class>, Code=<code>].**

---

**Error Type:**

Warning

**Result:**

1. If device error (such as transport, protocol, or access) occurred:

- If tag is a block tag, the entire block (address -> address + block size) will be deactivated. All tags within that block will be deactivated. This is signified by the postfix message "...Block Deactivated."
- If tag is an array tag or string tag, just this tag will be deactivated. This is signified by the postfix message "...Tag Deactivated."

2. If no device errors occurred:

- If tag is a block tag, the entire block will be invalidated. All tags within that block will be invalidated.
- If tag is an array tag or string tag, just this tag will be invalidated.

**Possible Cause:**

An S7 Messaging error occurred. This will occur if this portion is malformed or contains incorrect packet lengths.

**Solution:**

Contact Technical Support.

**See Also:**

[Error Codes](#)

**Unable to read <block size> bytes starting at address <address> on device <device name>. Device returned transport error [Code=<code>].**

---

**Error Type:**

Warning

**Result:**

1. If device error (such as transport, protocol, or access) occurred:

- If tag is a block tag, the entire block (address -> address + block size) will be deactivated. All tags within that block will be deactivated. This is signified by the postfix message "...Block Deactivated."
- If tag is an array tag or string tag, just this tag will be deactivated. This is signified by the postfix message "...Tag Deactivated."

2. If no device errors occurred:

- If tag is a block tag, the entire block will be invalidated. All tags within that block will be invalidated.
- If tag is an array tag or string tag, just this tag will be invalidated.

**Possible Cause:**

An RFC1006 error (ISO over TCP/IP) occurred. This is the portion of the packet that encapsulates the S7 Messaging packet.

**Solution:**

Contact Technical Support.

**See Also:**

[Error Codes](#)

---

**Unable to read <block size> bytes starting at address <address> on device <device name>. Frame contains errors.**

---

**Error Type:**

Warning

**Result:**

1. If device error (such as transport, protocol, or access) occurred:

- If tag is a block tag, the entire block (address -> address + block size) will be deactivated. All tags within that block will be deactivated. This is signified by the postfix message "...Block Deactivated."
- If tag is an array tag or string tag, just this tag will be deactivated. This is signified by the postfix message "...Tag Deactivated."

2. If no device errors occurred:

- If tag is a block tag, the entire block will be invalidated. All tags within that block will be invalidated.
- If tag is an array tag or string tag, just this tag will be invalidated.

**Possible Cause:**

1. The TPDU response size is incorrect.
2. An unexpected frame was received. The response code may also be incorrect.
3. The frame sequence is out of order.
4. The device's CPU work load is too high.
5. If the tag address references a TOD data type, the DWORD value may be larger than the number of milliseconds in a day. For example, 86400000.

**Solution:**

1. Cable noise may cause distortion in the frame, resulting in erroneous data. It may also cause dropped frames. Verify the cabling between the PC and the PLC's device.
2. Reduce network traffic. If this error occurs frequently, increase the Request Timeout and/or Fail After attempt count.
3. Decrease the tag group scan rate to reduce the work load on the PLC's CPU.
4. Increase the "Scan Cycle Load from Communication" and "Scan Cycle Monitoring Time".
5. Change the value in the device to a valid DWORD that can be converted to a time that is less than or equal to 23:59:59.999.

**See Also:**[Error Codes](#)

---

**Unable to read <block size> bytes starting at address <address> on device <device name>. NetLink returned error [Code=<code>].**

---

**Error Type:**

Warning

**Result:**

1. If device error (such as transport, protocol, or access) occurred:

- If tag is a block tag, the entire block (address -> address + block size) will be deactivated. All tags within that block will be deactivated. This is signified by the postfix message "...Block Deactivated."
- If tag is an array tag or string tag, just this tag will be deactivated. This is signified by the postfix message "...Tag Deactivated."

2. If no device errors occurred:

- If tag is a block tag, the entire block will be invalidated. All tags within that block will be invalidated.
- If tag is an array tag or string tag, just this tag will be invalidated.

**Possible Cause:**

An error was returned from the PLC or NetLink adapter.

**Solution:**

1. If the error code=0x11, an incorrect MPI ID may be set. Determine the MPI ID through which communications are occurring, and then re-enter it in the MPI ID Device Property field.
2. If the error code=0x87, users may be accessing data out of range in the device. Verify the device's address limits, and then correct the tag references causing the error.
3. For all other errors, contact Technical Support.

**See Also:**

[Error Codes](#)

**Unable to write to <address> on device <device name>. Device not responding.**

---

**Error Type:**

Warning

**Result:**

The write operation to the address failed.

**Possible Cause:**

1. The connection between the device and the host PC is broken.
2. The named device may have been assigned an incorrect IP address.
3. The device's CPU work load is too high.

**Solution:**

1. Verify the cabling between the PC and the PLC's device.
2. Verify the IP address given to the named device matches that of the actual device.
3. If this error occurs frequently, decrease the tag group scan rate to reduce the work load on the PLC's CPU.
4. Increase the "Scan Cycle Load from Communication" and "Scan Cycle Monitoring Time".

**Unable to write to <address> on device <device name>. Device returned data access error [Code=<code>].**

---

**Error Type:**

Warning

**Result:**

The write operation to the address failed.

**Possible Cause:**

A data access error occurred. This will occur if, for instance, a requested address is out of range or is being referenced incorrectly.

**Solution:**

Contact Technical Support.

**See Also:**

[Error Codes](#)

---

**Unable to write to <address> on device <device name>. Device returned protocol error [Class=<class>, Code=<code>].**

---

**Error Type:**

Warning

**Result:**

The write operation to the address failed.

**Possible Cause:**

An S7 Messaging error occurred. This will occur if this portion is malformed or contains incorrect packet lengths.

**Solution:**

Contact Technical Support.

---

**Unable to write to <address> on device <device name>. Device returned transport error [Code=<code>].**

---

**Error Type:**

Warning

**Result:**

The write operation to the address failed.

**Possible Cause:**

An RFC1006 error (ISO over TCP/IP) occurred. This is the portion of the packet that encapsulates the S7 Messaging packet.

**Solution:**

Contact Technical Support.

---

**Unable to write to <address> on device <device name>. Frame contains errors.**

---

**Error Type:**

Warning

**Result:**

The write operation to the address failed.

**Possible Cause:**

1. The TPDU response size is incorrect.
2. An unexpected frame was received. The response code may be incorrect.
3. The frame sequence is out of order.
4. The device's CPU work load is too high.

**Solution:**

1. Cable noise may cause distortion in the frame, resulting in erroneous data. It may also cause dropped frames. Verify the cabling between the PC and the PLC's device.
2. Reduce network traffic. If this error occurs frequently, increase the Request Timeout and/or Fail After attempt count.
3. If this error occurs frequently, decrease the tag group scan rate to reduce the work load on the PLC's CPU.
4. Increase the "Scan Cycle Load from Communication" and "Scan Cycle Monitoring Time".

---

**Unable to write to <address> on device <device name>. NetLink returned error [Code=<code>].**

---

**Error Type:**

Warning

**Result:**

The write operation to the address failed.

**Possible Cause:**

An error was returned from the PLC or NetLink adapter.

**Solution:**

1. If error code=0x11, an incorrect MPI ID may be set. Determine the MPI ID through which communications are occurring, and then re-enter it in the MPI ID Device Property field.
2. If error code=0x87, users may be accessing data out of range in the device. Verify the device's address limits, and then correct the tag references causing the error.
3. For all other errors, contact Technical Support.

---

**Unable to write to <address> on device <device name>. Time of Day string <write string> contains a syntax error. Expected hh:mm:ss.hhh format.**

---

**Error Type:**

Warning

**Result:**

The write operation to the address failed.

**Possible Cause:**

The string that will be written is not in the correct *hh:mm:ss.hhh* format.

**Solution:**

Format the string correctly.

---

**Unable to write to address <address> on device <device>. Date string <write string> contains a syntax error. Expected yyyy-mm-dd format.**

---

**Error Type:**

Warning

**Result:**

The write operation failed.

**Possible Cause:**

The string is not in the correct format.

**Solution:**

Format the string using the correct *yyyy-mm-dd* format.

---

**Unable to write to address <address> on device <device>. Time string <write string> contains a syntax error. Expected ddD\_hhH\_mmM\_ssS\_hhhMS format.**

---

**Error Type:**

Warning

**Result:**

The write operation failed.

**Possible Cause:**

The string is not in the correct format.

**Solution:**

Format the string using the correct *ddD\_hhH\_mmM\_ssS\_hhhMS* format.



# Index

## A

**Address <address> is out of range for the specified device or register. 64**

**Address Descriptions 39**

**Address Validation Error Messages 64**

**Addressing Options 9**

**Appicom Direct-Link Item Syntax 48**

**Array size is out of range for address <address>. 64**

**Array support is not available for the specified address:<address>. 64**

**Automatic Tag Generation Error Messages 65**

## B

**BCD 38**

**Big Endian 9**

**Boolean 38**

## C

**Cable Diagrams 12**

**Communications Parameters 7**

**Configuring Connections 6-7, 16**

**CP 7**

## D

**Data type <type> is not valid for device address <address>. 65**

**Data Types Description 38**

**Device <device name> is not responding. 72**

**Device address <address> contains a syntax error. 65**

**Device address <address> is read only. 65**

**Device ID 6**

**Device Status Error Messages 71**

**Driver Error Messages 70**

**DWord 38**

**E**

**Error Codes 63**

**Error Descriptions 63**

**F**

**Float 38**

**H**

**Help Contents 5**

**How To Configure S7-1200 Connections with the Totally Integrated Automation (TIA) Portal 31**

**How To Configure S7-1500 Connections 35**

**How To Configure S7-200 Connections in Micro/WIN 13**

**How To Configure S7-300/400 Connections in STEP 7 27**

**I**

**INAT OPC Server TCPIPH1 Item Syntax 50**

**Internal Tags 43**

**L**

**Language file warning for device <channel.device>: Memory exception reading the STEP 7 language file. 66**

**Language file warning for device <channel.device>: STEP 7 language file failed to open [Reason]. 66**

**Language file warning for device <channel.device>: Unable to load STEP 7 language file. 66**

**LBCD 38**

**Legacy S7-300/400 Item Syntax 58**

**Little Endian 9**

**Long 38**

**M**

**MicroWin 13**

**Missing address. 65**

**N**

**NetLink 7**

**NetLink: S7-300 Address Descriptions 42**

**NetLink: S7-400 Address Descriptions 42**

**Network 6**

**O**

**Optimizing Siemens TCP/IP Ethernet Communications 37**

**Overview 5**

**S**

**S7-1200 Address Descriptions 41**

**S7-1500 Address Descriptions 42**

**S7-200 Address Descriptions 39**

**S7-300 Address Descriptions 41**

**S7-400 Address Descriptions 41**

**S7 Communications Parameters 7**

**Short 38**

**Siemens Simatic Net Item Syntax 52**

**Siemens STEP 7 Item Syntax 54**

**Softing S7/S5 OPC Server Item Syntax 56**

**Standard S7-300/400/1200/1500 Item Syntax 43**

**STEP 7 27**

**String conversion warning: Auto generated tag names and descriptions may not appear as expected for device <channel.device>. 67**

**T**

**Tag Import 10**

**TIA Portal 31**

**U**

**Unable to connect to device <device name>. Device returned transport error [Code=<code>]. 72**

**Unable to connect to device <device name>. Frame contains errors. 73**

**Unable to establish association with device <device name>. Device returned protocol error [Class=<class>, Code=<code>]. 73**

- Unable to establish association with device <device name>. Device returned transport error [Code=<code>]. 74
- Unable to establish association with device <device name>. Frame contains errors. 74
- Unable to generate a tag database for device <channel.device>. Reason: The program path has not been specified. 67
- Unable to generate a tag database for device <channel.device>. Reason: The STEP 7 project file has not been specified. 67
- Unable to generate a tag database for device <device name>. Reason: <model> devices do not support auto tag database generation. 67
- Unable to generate a tag database for device <device name>. Reason: Failed to read data from the STEP 7 project. 68
- Unable to generate a tag database for device <device name>. Reason: File system error processing the STEP 7 project. 68
- Unable to generate a tag database for device <device name>. Reason: Internal driver error occurred. 68
- Unable to generate a tag database for device <device name>. Reason: The specified CPU is not supported. 69
- Unable to generate a tag database for device <device name>. Reason: Unable to open STEP 7 project. 69
- Unable to generate tag(s) on device <device> for <data block name> data block <data block number>. 69
- Unable to generate tag(s) on device <device> for <tag group>. Array tag not supported for data type <data type>. Tag <tag name> not created. 69
- Unable to generate tag(s) on device <device> for <tag group>. Created tag <tag name> with address <tag address> due to internal block size. 70
- Unable to read <block size> bytes starting at address <address> on device <device name>. Device returned data access error [Code=<code>]. 75
- Unable to read <block size> bytes starting at address <address> on device <device name>. Device returned protocol error [Class=<class>, Code=<code>]. 76
- Unable to read <block size> bytes starting at address <address> on device <device name>. Device returned transport error [Code=<code>]. 76
- Unable to read <block size> bytes starting at address <address> on device <device name>. Frame contains errors. 77
- Unable to read <block size> bytes starting at address <address> on device <device name>. NetLink returned error [Code=<code>]. 77
- Unable to write tag <address> on device <device name>. 78
- Unable to write tag <address> on device <device name>. Device not responding. 78
- Unable to write tag <address> on device <device name>. Device returned protocol error [Class=<class>, Code=<code>]. 79
- Unable to write tag <address> on device <device name>. Device returned transport error [Code=<code>]. 79
- Unable to write tag <address> on device <device name>. Frame contains errors. 79
- Unable to write tag <address> on device <device name>. NetLink returned error [Code=<code>]. 79
- Unable to write tag <address> on device <device name>. Time of Day string <write string> contains a syntax error. Expected hh:mm:ss.hhh format. 80
- Unable to write to address <address> on device <device>. Date string <write string> contains a syntax error. Expected yyyy-mm-dd format. 80
- Unable to write to address <address> on device <device>. Time string <write string>

contains a syntax error. Expected ddD\_hhH\_mmm\_ssS\_hhhMS format. 80

## W

**Windows code page warning for device <channel.device>: A required code page (<nnnn>) is unavailable on this machine. Tag generation may fail or tag names and descriptions may not appear as expected. 70**

**Winsock initialization failed (OS error = n). 71**

**Winsock V1.1 or higher must be installed to use the Siemens TCP/IP Ethernet device driver. 71**

**Word 38**